


We keep your drive running!




Peak analyzer Manager



Manual Version 3.0.0

www.maschinendiagnose.de



Peakanalyzer Manager

Manual Version 3.0.0

GfM Gesellschaft für Maschinendiagnose mbH
Berlin, 26 August, 2019

Content

1 Preamble.....	5
2 Introduction	7
3 First Steps.....	8
3.1 System requirements	8
3.2 Installation.....	8
3.3 Network Settings	8
4 General	10
4.1 Language	10
4.2 SQL-Server Settings	10
4.3 Program Overview	11
4.4 Add Peakanalyzer	12
4.5 Bearing database	12
4.6 Machine templates	13
5 Peakanalyzer	15
5.1 Properties.....	15
5.1.1 Hardware Equipment	15
5.1.2 System	16
5.1.3 Access Rights	16
5.1.4 Online Status.....	17
5.2 Configuration.....	18
5.2.1 General	20
5.2.2 Inputs	22
5.2.2.1 Bus Channels.....	22
5.2.2.2 Speed Channels.....	25
5.2.2.3 Counter Channels	26
5.2.2.4 Vibration Channels.....	27
5.2.2.5 Virtual Process Channels.....	28
5.2.2.6 Process Channels	29
5.2.3 Base Diagnosis	31
5.2.3.1 Characteristic Values	31
5.2.3.2 Process Factors	33
5.2.3.3 Classification.....	35
5.2.4 Advanced Diagnosis	35
5.2.4.1 Drive Elements.....	35
5.2.4.2 Diagnosis Conditions	41
5.2.5 Communication	42
5.2.5.1 Bus Outputs	42
5.2.5.2 Digital Outputs.....	45
5.2.5.3 Current Outputs.....	46
5.2.5.4 Remote.....	46
5.2.5.5 E-Mail	47
5.2.6 Storage Management.....	49
5.3 Service Measurement	50
5.4 Data Management	50
5.4.1 Cyclic Download.....	51
5.4.2 Backup Strategies	51
5.4.3 Download Data.....	52
5.5 Logbook	53
5.5.1 Alerting	54
5.5.2 Device states.....	54
5.5.3 Diagnosis states.....	54
5.5.4 Data storage.....	54

- 5.5.5 User access 54
- 5.6 Status Messages 55
 - 5.6.1 Threshold Settings 56
 - 5.6.2 Status Messages Description..... 59
- 6 PeakStore5 62
 - 6.1 Configuration..... 62
 - 6.1.1 General 63
 - 6.1.2 Speed Channels..... 64
 - 6.1.3 Vibration Channels..... 65
 - 6.1.4 Characteristic Values 66
 - 6.1.5 Protocol Template 67
 - 6.2 Vibration Measurement..... 67
 - 6.2.1 Sensor Overview..... 68
 - 6.2.2 Measurement Protocol..... 69
 - 6.2.3 Time Signals 70
 - 6.2.4 Spectra..... 71
 - 6.2.5 Characteristic Values 72
 - 6.3 Balancing 72
 - 6.3.1 Preparation..... 73
 - 6.3.2 Origin Measurement..... 74
 - 6.3.3 Test Measurement 75
 - 6.3.4 Validation Measurement 75
 - 6.3.5 Finalization 75
 - 6.4 Data Management 76
 - 6.5 Remote Control..... 78
- 7 Diagnostic Tool 80
 - 7.1 Licensing..... 80
 - 7.2 Measurement Selection 81
 - 7.3 Preprocessing 82
 - 7.4 Base Diagnosis 85
 - 7.5 Advanced Diagnosis 86
 - 7.6 Calculation 87
- 8 Machine Overview 88
 - 8.1 General Information 90
 - 8.2 Sensor Overview..... 90
 - 8.3 Alarms Vibration Diagnosis..... 92
 - 8.4 Alarms Characteristic Values..... 92
 - 8.5 Alarms Process Factors..... 92
- 9 Analysis..... 94
 - 9.1 Data Selection..... 94
 - 9.2 Curve Window..... 94
 - 9.3 Toolbar..... 95
 - 9.4 Cursor 103
 - 9.4.1 Measurement Cursor 103
 - 9.4.2 Harmonic Cursor 104
 - 9.4.3 Sideband Cursor 105
 - 9.4.4 Marking Cursor..... 106
 - 9.5 Filter Settings 107
 - 9.6 Selection of Diagnostic Attributes 107
 - 9.7 Trend Visualisation 108

1 Preamble

A rolling bearing damage of an industry gear box is expensive. Mostly not only the rolling bearing has to be replaced. The toothing is also damaged if the rolling bearing damage has lead to a displacement of the shaft. These elements have to be purchased. There will also arise working hours of the installing person. Then there will also arise costs of the production loss. But if you recognize the rolling bearing damage early enough consequential damages can be prevented and the repair can be made during a planned stoppage. Production losses are prevented extensively.

The Peakalyzer can not prevent damages but it enables automatically recognition of damages in the beginning and automatic alerting.

- Cost-intensive, low redundancy drives like mills in the cement industry
- Drives with a particular relevance of availability like drives of the conveyance system,
- Especially security relevant drives like drives of cable trains and
- Drives like wind energy turbines which have to be stringently subject to a predictive maintenance because they are e.g. hardly accessible.

The Peakalyzer enables

- The automatic vibration diagnostic on up to 16 measuring points and alarm only if irregularities are detected,
- The process factor monitoring on up to 4 measuring points,
- The rain flow classification of up to 2 process variables,
- Particle counting in the lubricant at 2 counter inputs,
- Base monitoring of Wind Turbine Generators
- The logging of the asset history of the drive for a later determination of failure causes as also
- The possibility to make service measurements, independent of the automatic vibration diagnosis without the possibility to read stored data of the automatic vibration diagnosis.

The Peakalyzer is constantly installed at the drive. Once started it works steadily with a minimum of effort for the system maintenance.

The control of one or multiple Peakalyzer is made with the program Peakalyzer Manager.

The kinematics data which arise from the construction have to be set at the Peakalyzer in a monitoring configuration. Out of it the Peakalyzer calculates automatically the relevant kinematics frequencies and orders.

The evaluation of the amplitudes occurs automatically according to a patented universal mathematic method. So it is not necessary to set limit values for the amplitudes. Consequently there do not exist uncertainties which exist at other systems by setting subjectively amplitude limit values. It is also no learning process necessary.

Loading a configuration monitoring, handling alarms, the sifting of data and the implementation of service measurements can be performed directly on the Peakalyzer by connecting a computer via Ethernet or via modem. The Ethernet port provides the ability to connect with the Peakalyzer from different router via DSL, ISDN, GSM, UMTS or LTE.

We wish our customers that the Peakalyzer proves to be an useful tool for the predictive maintenance. We would appreciate to receive suggestions which would lead to an improvement of the Peakalyzer or the present manual.

Now we would like to offer the seminars of GfM Gesellschaft für Maschinendiagnose mbH in which you get to know the basics of machine diagnosis. These basics are helpful for working with the Peakalyzer especially for the configuration and interpretation of diagnostic data.

GfM Gesellschaft für Maschinendiagnose mbH
Köpenicker Straße 325, Haus 40
12555 Berlin (Germany)
Tel +49 30 / 6576 2565
Fax +49 30 / 6576 2564
Internet www.maschinendiagnose.de
E-Mail mailbox@maschinendiagnose.de

2 Introduction

This manual describes the installation, configuration and usage of the software Peakalyzer Manager. The Peakalyzer Manager can manage an arbitrary number of Peakalyzer in the network. Via the Peakalyzer Manger a diagnostician can communicate with the Peakalyzer and control it. It allows to:

- create monitoring configurations and transmit them to the assigned Peakalyzer
- view and evaluate the data that is generated on the Peakalyzer during the monitoring
- handle alarms that are generated on the Peakalyzer
- do service measures

Additional features like marking diagnosis attributes, filter the data and usage of trend visualization makes it easier to diagnose .

Installed Peakalyzer on machines or engines can be structured in an hierarchical and well observable view with the Peakalyzer Manager.

3 First Steps

3.1 System requirements

For the usage of the Peakalyzer Manager is a PC with latest drivers required that fulfill the following system requirements:

Minimum:

- Windows 7
- RAM: 4 GB
- Processor: 2 x 1.6 GHz
- Graphic: 256 MB RAM

Recommended:

- Windows 7, Windows 8, Windows 10
- RAM: 8 GB
- Processor: 4 x 2 GHz
- Graphic: 512 MB RAM

3.2 Installation

The following operation systems are supported:

- Windows 7
- Windows 8
- Windows 10

For the installation of the Peakalyzer Manager the installation CD must be put in a suited drive in the PC. If the installation program does not start automatically, the installation can be started by manually executing the file PM_Setup.exe on the installation CD. Administrator privileges are required for the installation process.

It is advised to follow the instructions during the installation process. It is recommended to install the program Peakalyzer Manager in the proposed directory.


The installation program will check whether up to date versions of .NET Framework and DirectX 9.0c are installed on the PC. If necessary these programs will be updated.

Also a free version of the Microsoft® SQL Server® 2012 Express will be installed on the PC. It serves as data storage for measured and evaluated data that are generated on the Peakalyzer. The free version of the Microsoft® SQL Server® 2012 Express supports 10 GB of data storage for each Peakalyzer. This suits for a standard configuration for measurement data of approximately 2 years. If a configuration is used with a smaller storage interval or the measurement data in the Peakalyzer Manager should be available more than 2 years, it is highly recommended to use a product line of the Microsoft® SQL Server® that does not have the 10 GB limitation per database.

After the installation there is link of the Peakalyzer Manager in the program group GfM in the start menu.

3.3 Network Settings

To establish a connection to the Peakalyzer the network settings of the PC may be adopted. The Peakalyzer must be in the same subnet as the Peakalyzer or an active route to the subnet of the Peakalyzer must be present.



4 General

4.1 Language

After the first start of the Peakalyzer Manager the language is set according to the language settings of the operating system. If the operating system is set to German, the Peakalyzer Manager will start in German. Otherwise language is chosen.


In the menu Extras → Options the language can be changed on the tab language. To apply these changes the program Peakalyzer Manager must be restarted.

4.2 SQL-Server Settings

To work properly with the Peakalyzer Manager, a connection to a Microsoft® SQL Server® 2012 must be present. If the Peakalyzer Manager was installed with default settings, the connection to the installed Microsoft® SQL Server® 2012 Express was automatically configured.

It is also possible to use a Microsoft® SQL Server® 2012 that is installed on another PC in the local net. Thus multiple PCs in the same network can have installed the Peakalyzer Manager and use all the same database server.

The connection to a Microsoft® SQL Server® 2012 can be changed during runtime by entering the SQL server name and login credentials in the menu point Extras → SQL-Login.




Furthermore multiple user on this SQL-Server can be configured in the menu Extras → SQL-Settings to allow individual access for different persons. This setting is only available for administrators.

The following access rights are available:

- Administrator: can add further users
- Standard user: can do all actions except adding new user
- Read-Only user: can only view and export data and configurations.
- Restricted user: has same rights as read-only user but can do measurements of PeakStore devices as well as export and delete these measurements

Additionally users can be deleted and passwords of other users can be changed.



If the login data of the installed Microsoft® SQL Server® 2012 Express are lost, it is possible to login with the following SQL login data:

Username: sa

Password: P@s\$w0rdP@s\$w0rd

It is highly recommended to immediately create a new administrator in the menu Extras → SQL Settings and relogin with the new user via Extras → SQL Login.

4.3 Program Overview

There is a tree view on the left side of the Peakalyzer Manager which can be nested arbitrary deep by the user. It serves as an overview for the monitored machines and engines. In this view multiple Peakalyzer can be added in each layer. The state of the underlying layers is visualized by the color of the node.

If there is an alarm on one Peakalyzer, the node of the Peakalyzer and all parent nodes are colored red. If all alarms are handled, the node will be colored green.

View

The view of the hierarchical structure can be switched between the modes monitoring and measurement devices. In the view measurement devices the Peakanalyzers are faded in. Only in this view it is possible to do the following actions:

- query properties of the Peakalyzer, like:
 - read hardware equipment
 - view and update license information
 - view and change IP settings
 - view and change access rights
 - query the online state of the current monitoring state
- view, change, save and transmit configurations of the Peakalyzer
- do a service measure based on the current monitoring configuration

The Peakalyzer is faded out in the monitoring view. Therefore a pure view on the state of the monitored machines is possible.

If one or multiple machines are monitored by one Peakalyzer, these are listed in the measurement devices view below the Peakalyzer. In the monitoring view these machines are listed below the higher level layer.

Furthermore multiple Peakalyzer can be configured to monitor one machine. This machine would occur multiple times in the measurement devices view, namely in each Peakalyzer that monitor this machine. In the monitoring view this machine occur only once and all data off all Peakalyzer are merged together. If multiple machines are monitored by one Peakalyzer, they are listed under the Peakalyzer in the measurement view. In the monitoring view they are listed below the higher level layer.

For the measurement devices view the display can be modified. In the menu View → Display it can be chosen between the following one:

- name of the Peakalyzer
- name of the configuration
- location

The name of the Peakalyzer is the default option.

Furthermore it is possible to move the hierarchical layers per Drag & Drop. This can be enabled by activating the menu View → Modify hierarchy.

4.4 Add Peakalyzer

A new Peakalyzer can be integrated in the system by selecting diagnosis system → New → Peakalyzer in the menu or context menu in the hierarchical tree view. The Peakalyzer will be added to the current selected hierarchical layer.

The local network can be searched for existing Peakalyzer. If one Peakalyzer is taken, all needed settings will be set. If the Peakalyzer is not in the list, the settings can be set manually.

The following information are required:

- Device name of the Peakalyzer: The name has the following schema: CX-123ABC. This information can be found on the Peakalyzer
- Location: An optional description for the location of the Peakalyzer
- IP-Address of the Peakalyzer
- Alternatively a network name can be set. This network name must be resolved to the correct IP-Address of the Peakalyzer by an name server
- Port for the communication to the Peakalyzer: Furthermore the following 4 ports are used for the communication to the Peakalyzer. The default ports are 8521-8524
- Database name: The database name is set automatically when the device name is changed and usually must not be changed.

4.5 Bearing database

Under the menu point Templates → Bearing Database a repository of bearing types can be created. The required information can be generally obtained from the bearing manufacture. The configured bearing types can than be used in machine configurations, e.g. on the Peakalyzer. Thus the bearing information can be maintained on a central and the amount of erroneous inputs during the kinematic configuration is reduced.

Name	Rotational cage order	Ball spin order	2 x ball spin order	Ball pass order outer ring	Ball pass order inner ring
FAG 20219		0.418	2.963	5.926	9.313
FAG 20228		0.421	3.095	6.19	9.839
FAG 20230		0.427	3.343	6.686	10.317
FAG 20320		0.396	2.311	4.622	7.846
FAG 22211ES		0.42716	3.32	6.64	10.88396
FAG 22212ES		0.41913	2.973615	5.94723	9.87472
FAG 22213ES		0.423	3.14	6.28	10.382
FAG 22214ES		0.428	3.3415	6.683	10.876
FAG 22216ES		0.427	3.321	6.642	10.886
FAG 22217es		0.423	3.1415	6.283	10.383
FAG 22218EAS		0.423	3.143	6.286	10.381
FAG 22219ES		0.42336	3.14676	6.29352	10.37952
FAG 22220ES		0.423	3.133	6.266	10.385
FAG 22309ES		0.408	2.5625	5.125	8.284
FAG 22310ES		0.403	2.4135	4.827	8.357
FAG 22311ES		0.40305	2.413985	4.82797	8.35729
FAG 22312ES		0.40301	2.41469	4.82938	8.35779
FAG 22313ES		0.409	2.593	5.186	8.864
FAG 22314es		0.402	2.405	4.81	8.366
FAG 22315ES		0.40245	2.404415	4.80883	8.36572
FAG 22316ES		0.402	2.4045	4.809	8.366
FAG 22317ES		0.40247	2.40798	4.81596	8.36549
FAG 22318EC		0.4025	2.4074	4.8148	8.3654
FAG 22319ES		0.402	2.4075	4.815	8.365
FAG 22320ES		0.402	2.4045	4.809	8.366
FAG 22322ES		0.409	2.591	5.182	8.867
FAG 22322 (Kissling)		0.425	3.161	6.322	10.358
FAG 22324ES		0.402	2.4075	4.815	8.366


This bearing database can also be exported to a separate file for porting on another Peakalyzer Manager or to backup the current database.

If the Peakalyzer Manager and the corresponding SQL database is newly installed on a system, the bearing database is initially empty. The GfM Gesellschaft für Maschinendiagnose mbH does not provide a bearing database for liability reasons. The bearing database must be created and maintained by the user itself.

If multiple Peakalyzer Manager in the same network use the same SQL database and multiple user edit the bearing database simultaneously, it is possible that changes to bearings that are already edited by another user are withdrawn. In this case an appropriate message is shown.

4.6 Machine templates

Under the menu point Templates → Machine templates complete drive chains can be managed. This is helpful if multiple machines of the same type are monitored by different systems. Thus the machine type must be only created once as template and can then be applied to the actual machine. By pressing the button "Add machine template" a new template can be created. The name of the template can be directly edited in the left list. Now the complete drive chain can be configured for this created machine template. Details for the different available drive elements can be found in the chapter [drive elements](#). The configured machine template can be used by e.g. the configuration of a Peakalyzer.




5 Peakalyzer

5.1 Properties

The properties of the Peakalyzer can be queried by selecting the menu point "Diagnosis system" → Properties or the button Properties in the navigation bar at the bottom. For this action an active LAN connection to the Peakalyzer must be established. During the query process the device name of the Peakalyzer on the device and in the local database will be verified. If they do not match, the device name in the local database can be adjusted to the correct device name.


5.1.1 Hardware Equipment



On the tab hardware equipment the automatically detected in- and output channels of the Peakalyzer are listed. The button Rescan forces the Peakalyzer to rescan the hardware equipment. This can be useful if the Peakalyzer is extended by additional in- or output channels or when the expected hardware equipment does not match with the listed. By clicking on the button an additional warning appears that the Peakalyzer needs to restart to run the hardware scan. This procedure can take 5 - 10 minutes. During this time the Peakalyzer is not available via the Peakalyzer Manager. When the procedure is finished the properties can be queried again to verify the new hardware settings.

Furthermore the stored license information can be seen on this tab. These license information are checked during the normal monitoring to ensure that the maximum amount of configured channels for machine diagnosis does not exceed the licensed number of channels. On each Peakalyzer, delivered by GfM Gesellschaft für Maschinendiagnose mbH, is already the ordered number of diagnosis channels licensed. If the existing Peakalyzer should be extended, the license can also be extended. The button "update license" allows to select and store a new license on the Peakalyzer. The settings are applied immediately and the contained number of diagnosis channels are listed. Detailed information about the licensing are provided at an extension of the Peakalyzer.

5.1.2 System




On the tab system is the network configuration of the Peakalyzer listed. By clicking on the button Change the network settings of the Peakalyzer can be modified. A new window will open where the following information can be set:

- *Resolve IP Address automatically* The Peakalyzer requests the network configuration from an existing DHCP-Server
- *IP-Address*
- *Subnet mask*
- *Gateway*
- *DNS-Server*
- *NTP-Server* If an NTP-Server is configured, the Peakalyzer will synchronize to the time server once an hour.
- *Ports* TCP and UDP Ports for the communication to the Peakalyzer

Furthermore the current firmware version of the Peakalyzer will be displayed. If the firmware of the Peakalyzer does not match with the stored firmware in the Peakalyzer Manager, the firmware can be updated.

5.1.3 Access Rights




On the tab access rights individual privileges for multiple user for the access on the Peakanalyzer can be configured. These are saved on the Peakanalyzer and will be queried on each access to the Peakanalyzer. The following access rights can be set:

- *Administrator* has all other rights and can add, delete or modify all other users
- *Change configuration* Allows to transmit and modify the configuration on the Peakanalyzer
- *Service measure* Allows to do a service measurement based on the current monitoring configuration
- *Acknowledge alarms* Allows to acknowledge or reset the current alarms on the Peakanalyzer
- *Read data* Allows to read the saved measurement data and alarm notifications on the Peakanalyzer
- *Delete data* Allows to delete measurement data directories on the Peakanalyzer

By default the user admin (with password: admin) is pre-configured on the Peakanalyzer. It is recommended to change this password.

5.1.4 Online Status



The current executing task of the monitoring process can be seen on the tab "Online Status". Thus it is possible to trace, whether the Peakanalyzer works correctly. The following steps can be seen:

- Check Preconditions
- Measure
- Analyze

If the Peakalyzer has a Profibus-Slave terminal or a Profinet-Device terminal equipped, the error state of the corresponding terminal can be queried. The state is queried when the button update is pressed.

5.2 Configuration

In this chapter the configuration of a Peakalyzer for monitoring one or multiple machines is described. If the hardware equipment of the Peakalyzer is known beforehand, the configuration can be created without an active connection to the Peakalyzer. Only for transmitting the configuration on the Peakalyzer an active connection is required again. An access to the configuration is only available if the Peakalyzer is selected on the left tree view.

New Configuration

If the hardware equipment is known beforehand a new configuration for monitoring engines and machines can be created via the menu point Configuration → New. If the hardware equipment is not known, a connection to the Peakalyzer will be established to download it. The new configuration will be filled with useful default settings.

Load Configuration

Via the menu point Configuration → Load the current configuration from the Peakalyzer, the last modified configuration or a previously transmitted configuration can be loaded.

Import Configuration

Via the menu point Configuration → Import the configuration of another Peakalyzer can be applied to the currently selected one. This only works if both Peakalyzer have the same hardware equipment.

Export Configuration

Via the menu point Configuration → Export the selected configuration can be saved as a file. This can be imported on another Peakalyzer Manager by Diagnosis system → Import. Alternatively the configuration can be exported as pdf file.

Save Configuration

Via the menu point Configuration → Save the current monitoring configuration can be saved in the local database. This configuration can be transmitted to the Peakalyzer afterwards or can be edited again at a later time point.

Transmit Configuration

Via the menu point Configuration → Transmit the current configuration on the Peakalyzer will be stopped and saved as a backup on the Peakalyzer. Afterwards the new configuration will be transmitted to the Peakalyzer and started afterwards.

Start Monitoring

If the current configuration on the Peakalyzer is stopped, it can be restarted via the menu point Configuration → Start Monitoring.


Stop Monitoring

If the regular monitoring process should be stopped on the Peakalyzer, the menu point Configuration → Stop Monitoring can be chosen to stop the current configuration. Thus the Peakalyzer does not measure or analyze any data any more. This can be useful for a longer downtime of the monitored engine or machine. If a service measurement is initiated by the Peakalyzer Manager on the Peakalyzer, the configuration will also be stopped.

The configuration parts are described in the subsequently following sections.

5.2.1 General

On the tab General the following settings can be made:



Name of configuration

An arbitrary alphanumeric name. This name can be displayed in the left tree view instead of the name of the Peakalyzer.

Diagnosis sensitivity advanced diagnosis

The sensitivity for the advanced diagnosis of the system can be controlled by the diagnosis sensitivity. This is equivalent to the number of detections in series before a kinematic alarm notification is generated. A low number of detections in series (high sensitivity) leads faster to notifications but also increases the risk of false notifications. A high number of detections in series (low sensitivity) accordingly leads to better verified notifications. Thus a notifications is generated later on the Peakalyzer. Normally values from 3 to 5 detections in series are a reasonable setting.

Diagnosis sensitivity process factors

The sensitivity for the process factors of the system can be controlled by the diagnosis sensitivity. This is equivalent to the number of detections in series before a process factor warning or alarm notification is generated. A low number of detections in series (high sensitivity) leads faster to notifications but also increases the risk of false notifications. A high number of detections in series (low sensitivity) accordingly leads to better verified notifications. Thus a notifications is generated later on the Peakalyzer.

Diagnosis sensitivity characteristic values

The sensitivity for the characteristic values of the system can be controlled by the diagnosis sensitivity. This is equivalent to the number of detections in series before a warning or alarm notification of characteristic

values is generated. A low number of detections in series (high sensitivity) leads faster to notifications but also increases the risk of false notifications. A high number of detections in series (low sensitivity) accordingly leads to better verified notifications. Thus a notifications is generated later on the Peakalyzer.

Single Failure Mode

If this mode is activated, it is first searched for indications on imbalance, misalignment, gear damages or loose particles in the advanced analysis. Peaks in the spectrum that matches to these patterns are not used for indications of bearing damages. This mode is recommended for the configuration.

Monitor over-voltage protection

Commonly the Peakalyzer is equipped with an over-voltage protection for the network supply. If this over-voltage protection has an additional defect signal, it can be monitored by a digital input of the Peakalyzer. The Peakalyzer checks cyclically whether the over-voltage protection works appropriately and writes a corresponding notification in the logbook.

Monitored machines

The monitored machines must be set in the Peakalyzer. A new machine can be added to the monitoring configuration by clicking on "Add new machine". There must be at least one machine added to the configuration. It is also possible to add multiple machines. Furthermore machines can be added that are already monitored by other Peakalyzers. The monitoring of this machine is then extended by the sensors of the current Peakalyzer. If one machine is deleted from the monitoring list and there are still drive elements connected to this machine, all connected drive elements will be deleted.

5.2.2 Inputs

5.2.2.1 Bus Channels

If the Peakalyzer has a Profibus-Slave or a Profinet-Device, the according bus can be configured for additional input channels. These input channels can than be used as process channels or speed channels in the configuration. There can be up to two Profibus-Slave and two Profinet-Device terminals in one Peakalyzer. The further configuration identifies the channel by its name. For example the "Profibus 2 Channel 1" is the first channel of the second Profibus-Slave.

The telegram that is received via the bus is defined by the following table. The amount and type of defined channels determines the size of the telegram. The first two bytes of the telegram are used for an input identification. Only if the given input identifier is written in the telegram the following information are evaluated.

Each channel can be additionally multiplied with the scale factor, e.g. for scaling an integer value to an floating point range. Each channel can be configured with individual data types of the format 16 Bit Integer, 32 Bit Integer, 32 floating point or 64 Bit floating point. All data must be written in BigEndian format on the Master/Controller side.

Additionally one channel can be configured for alarm acknowledgment. By writing to this channel on the master/controller side it is possible to acknowledge all alarms of a given type on the Peakalyzer. The alarm acknowledge must be written for at least one second. The following bit pattern must be used:

Bit	Description
1	fixed value 1
2	fixed value 0
3	1 for alarm acknowledgment, otherwise 0
4	1 for alarm reset, otherwise 0. Only Bit 3 or 4 must be set.
5	fixed value 0
6	1 for acknowledgment of kinematic alarms
7	1 for acknowledgment of characteristic value alarms
8	1 for acknowledgment of process factor alarms. Bits 6-8 can be set together.
9-16	Percent value for alarm increase in the range 0-100 %

Exemplary follows a configuration with 3 input channels:


- 1st Channel: 32 Bit Floating Point
- 2nd Channel: 32 Bit Integer
- 3rd Channel: 16 Bit Integer

The telegram will then be the following:

Byte	Description
1 - 2	Input-Identification
3 - 6	32 Bit Floating Point Value of 1st Channel
7 - 10	32 Bit Integer Value of 2nd Channel
11 - 12	16 Bit Integer Value of 3rd Channel

Thus the telegram consists of 12 Bytes or 6 Word.

Profibus Channels




To use the Profibus for input channels the check for "Activate Input" must be set. Furthermore the Profibus-Slave-Address must be set that is agreed with the Profibus-Master. Afterwards the configuration of the input channels is done as described in [Bus Channels](#).

After transmitting the configuration the Profibus-Slave will be configured with the defined telegram in big endian format.

This telegram must be also defined on the corresponding Profibus-Master. In the program directory of the Peakalyzer the GSD file of the Profibus-Slave can be found which maybe is needed for configuring the Profibus-Master.

Profinet Channels




To use the Profinet-Device for additional input channels, the check "Activate Input" must be set. The MAC-Address of the Profinet-Device is provided on this site for the correct configuration of the Profinet-Device. Furthermore the last 4 numbers of the Profinet station name can be modified to avoid name conflicts with other devices. Afterwards the configuration of the input channels is done as described in [Bus Channels](#).

After transmitting the configuration the telegram with the defined size is applied on the Peakalyzer. The telegram size of the Profinet-Device is always round up to the next power of two. Thus there are only telegrams of the size 1, 2, 4, 8, 16, 32 or 64 WORD. The data is always transmitted in Big Endian format. The telegram structure must be configured on the Profinet-Controller in the same manner. The GSDML file of the Profinet-Device that may be necessary for the configuration of the Profinet-Controller can be found in the program directory of the Peakalyzer Manager.

5.2.2.2 Speed Channels

The speed channels can be configured on this tab.



For the measurement of the speed information, different physical input channels can be used. The following are available:

- **Speed Channels** Up to 4 Incremental-Encoder-Inputs can be configured on each Peakalyzer. They work with a very accurate impulse time point measurement method. This also delivers very accurate speed information if multiple non-equidistant impulses are placed per revolution. This is the recommended mode.
- **DC-Channels** The speed information can also be applied as voltage input (± 10 V) on an analog input channel. Thus the given voltage value is directly converted into a speed information.
- **Fixed Speed** If there is no external speed information available and the monitored machine operates with a constant speed, the fixed speed value can be given in this mode.

Properties speed processing

Some additional properties must be set for the different channel types:

Speed Channel:

- Number of impulses per revolution
- minimal and maximal speed where an analysis should take place. This is required to determine an optimal measurement time for the monitoring of certain drive elements later on.

- Activate counter channel: If the speed is connected via A/B lane, the position value can be measured as process factor. After activation the counter channel is available in the [process channels](#) section.

DC-Channel:


- Sensitivity in 1/min / V for the calculation of the speed value from the voltage value
- Offset if the voltage 0 V does not match to 0 1/min
- minimal and maximal speed where an analysis should take place. This is required to determine an optimal measurement time for the monitoring of certain drive elements later on.

Fixed Speed:

- Speed which is used for the calculation of order spectra from the frequency spectra.

5.2.2.3 Counter Channels

Counter channels for example for counting metal particle can be configured on this tab.




The following settings have to be set for the configuration of one counter channel:

- **Name** an arbitrary alphanumeric name for the description of measurement position
- **Channel** the physical input channel where the counter is connected to.
- **Warn threshold Absolute** If this absolute threshold value is exceeded a warn entry in the logbook is generated
- **Alarm threshold Absolute** If this absolute threshold value is exceeded an alarm is generated
- **Warn threshold Hour** If this hourly based threshold value is exceeded a warn entry in the logbook is generated
- **Alarm threshold Hour** If this hourly based threshold value is exceeded an alarm is generated
- **Warn threshold Day** If this daily based threshold value is exceeded a warn entry in the logbook is generated
- **Alarm threshold Day** If this daily based threshold value is exceeded an alarm is generated

- **Machine assignment** The counter channel can be assigned to one or multiple machines that are configured in the Peakalyzer. By default all machines are assigned to the counter channel.

5.2.2.4 Vibration Channels

The input channels for vibration acceleration and vibration distortion sensors, that are used for the diagnosis and specific value generation, can be configured on this tab.



The following settings have to be set for the configuration of one sensor:

- **Name** an arbitrary alphanumeric name for the description of measurement position
- **Channel** the physical input channel where the sensor is connected to. This can be a current driven IEPE-Channel for accelerometers in the measurement range ± 5 V or a DC-Channel for distortion sensor in the measurement range ± 10 V.
- **Reference Speed** A speed channel that was configured on the tab speed channels to generate order spectra from the time signal with this reference speed
- **Sensitivity / V** The sensitivity of the connected sensor. This information can be obtained from the sensor data sheet or a related calibration certificate.
- **Offset** The offset of the connected sensor. This information can be obtained from the sensor data sheet or a related calibration certificate.
- **Unit** The unit of the physical quantity that the sensor measure. This is "m/s²" for accelerometers and "m" for distortion sensors.
- **Lower cut-off frequency** Kinematic patterns of the advanced diagnosis are not searched below this set frequency. Default: 0 Hz
- **Highpass Envelope** The highpass filter for the calculation of the envelope signal can be individually adjusted. Default: 2kHz
- **IEPE current feed** If a IEPE-Channel is selected, the current feed can be chosen of the values 2, 4 or 8 mA which is relevant for long sensor cables. Default: 2 mA
- **Measurement Time [s]** The measurement time or measurement times that are configured for this sensor. For Peakalyzer SE the measurement time for the sensor must be configured with one of the given pool. In the normal version this serves only as an overview. The measurement time for the sensors is determined while assigning the drive elements to a sensor.


The following information are deduced from the above or serve as additional information and are configured on a different tab:

- **Measurement Range** This results from the selected input channel (IEPE or DC), sensitivity and offset of the sensor and the selected unit. The measured time signals can lie in this measurement range.
- **Sampling frequency [Hz]** The sampling frequency of the reduced time and envelope time signals that are saved for this sensor.

- *max. frequency* The maximum frequency that is contained in the resulting frequency and envelope frequency spectra.

5.2.2.5 Virtual Process Channels

On this tab virtual process channels can be created by the online calculation of two channels. The generated channel can be selected in the channel column on the process channel tab and further configured as described in process channels.



For the first and second channel all channel types are available that are available for the normal process channels and speed channels. The speed channel with incremental encoder interface (EL5151) must not be used if the signal is connected to clamp C. Only if the signal is connected to the A or A/B spur, the channel may be used for online calculation.

To each channel a multiplicative factor and an additive offset can be added. These two channels can be calculated to one new channel by the chosen basic arithmetic operation. The resulting channel can then be configured as any other process channel on the tab process channels. The chosen sampling frequency is then automatically applied to both channels.

It must be ensured by the user that the resulting virtual channel is configured with a resulting meaningful unit. The configurable unit on the tab process channels is applied to the resulting channel.

One concrete scenario for the usage of virtual process channels is the base monitoring of wind turbines (Product: Basealyzer). There a distortion sensor measures the movement between the base and the steel tube tower. An additional strain gauge measures the strain of the steel tube tower. The recalculation of the two inputs allows to monitor the actual movement between the base and the steel tube tower.

For example a distortion sensor at DC-Channel 1 with measurement range 3..13 mm and maximal output voltage of 10 V is used for the measurement of the distortion of the base. Furthermore a strain gauge (DMS-Channel 1) is applied on the steel tube tower. The strain gauge delivered by GfM has a maximum measurement voltage (U_M) of 25 mV with a supply voltage (U_V) of 5 V and a gage factor of $k = 2.1$ at 24 °C. Thus a relative length change ε can be calculated as follows:

$$\epsilon = \frac{U_M * 4}{U_V * k * 2,6}$$

With the above mentioned data a relative length change ϵ is calculated to about 0.0037 m/m ($\epsilon = 3,7$ mm/m). If the foundation component has a length of 3 m the length change is 11 mm at 25 mV measurement voltage U_M and therefore the sensitivity is 440 mm / V.

The configuration for the virtual channel is then parametrized as followed:


Factor 1: 1 (mm / V)
 Channel 1: DC-Channel 1
 Offset 1: 3 (mm)

Operand: Subtraction

Factor 2: 440 (mm / V)
 Channel 2: DMS-Channel 1
 Offset 2: 0 (mm)

It is reasonable to additionally configure the strain gauge as a separate [process channel](#). The [service measurement](#) provides the possibility to zero balance these configured strain gauge. This will save a configuration independent offset in the strain gauge box. The zero balancing in the service measurement should be only done if the steel tube tower is in normal position.

5.2.2.6 Process Channels



Process channels can be used to continuously measure process information. This can be e.g. power or temperature. These information can also be used to further restrict the analysis on certain operating point.

The following signals can be measured:

- analog voltage input ± 10 V
- analog current input 0..20 mA
- Strain Gauge ± 25 mV
- PT-100 Temperature sensors
- Digital Input
- digitalized signals via [Profibus](#)

First of all the physical quantity must be parametrized. Therefore the following parameters must be set:


- *Name* an arbitrary alphanumeric name for the connected process information (e.g. temperature)
- *Channel* the used analog input channel
- *Sampling frequency* sampling frequency of the analog channel selectable between 1 Hz and 1 kHz
- *Storage interval* selectable between 1 s and 99 min depending on the selected sampling frequency
- *Sensitivity / V and Offset* Conversion of the voltage value to the process information
- *Unit* an arbitrary description for the physical unit (e.g. °C)
- *Measurement range* This is calculated automatically by the given sensitivity, offset and unit
- *Machine assignment* The process information can be assigned to one or multiple machines that are configured in the Peakalyzer. By default all machines are assigned to the process channel.

The processing of the configured process channels is done in the next section: process factors.

Note: The sampling of the process channels is done without anti-aliasing and therefor can not be used for analysis in the frequency domain.

5.2.3 Base Diagnosis

5.2.3.1 Characteristic Values



On this tab the r.m.s. value of the vibration velocity and of the vibration acceleration can be set for the configured sensor channels.


The following parameters must be set for one sensor:

- **Sensor Selection** of a sensor that was configured in sensor channels
- **Characteristic Value**
 - DIN-ISO 10816-3 in vibration velocity or vibration acceleration: This characteristic value is calculated from the reduced time signal with the configured shorter measurement time and has the frequency bandwidth as stated in the [vibration channels](#) section.
 - DIN-ISO 10816-21 0,1 Hz - 10 Hz in vibration velocity or vibration acceleration with an evaluation period of 10 min
 - DIN-ISO 10816-21 10 Hz - 1 kHz in vibration velocity or vibration acceleration with an evaluation period of 1 min
 - DIN-ISO 10816-21 10 Hz - 2 kHz in vibration velocity or vibration acceleration with an evaluation period of 1 min
 - DIN-ISO 10816-21 10 Hz - 5 kHz in vibration velocity or vibration acceleration with an evaluation period of 1 min
 - Online r.m.s. of vibration velocity with 10 Hz high pass filter and adjustable low pass filter
 - Online r.m.s. of vibration acceleration with adjustable low pass filter
 - Online r.m.s. of vibration acceleration of envelope with adjustable low pass filter
 - Online arithmetic average without low pass filter
- **Low pass filter:** The low pass filter frequency in kHz that is used for filtering the raw time signal.
- **Averaging time:** Only required for online r.m.s. Each calculated characteristic value is averaged over the given period of the raw input signal.
- **Generation frequency:** Only required for online r.m.s. The generation frequency states how often the characteristic values are calculated.
- **Storage interval:** Only required for online r.m.s. The storage interval defines the time span that is used to aggregate the calculated characteristic values to one signal. Afterwards the statistical size is calculated from that signal and finally saved.
- **Statistical size:** Only required for online r.m.s. If maximum is chosen an alarm is generated if the learned or absolute threshold is exceeded. If minimum is chosen an alarm is generated if the learned or absolute threshold is shortfall.
- **Warn threshold** If the warn threshold is exceeded an warn notification is written in the logbook
- **Alarm threshold** If the alarm threshold is exceeded an alarm notification is generated.

- *Warn threshold increase* Only required for online r.m.s. and active [classification](#). The increase is calculated with the maximum r.m.s. of the learning phase after ending of the learning phase. It can be chosen between a percent or relative calculation of the threshold.
- *Warn threshold decrease* Only required for online r.m.s. and active [classification](#). The increase is calculated with the minimum r.m.s. of the learning phase after ending of the learning phase. It can be chosen between a percent or relative calculation of the threshold.
- *Alarm threshold increase* Only required for online r.m.s. and active [classification](#). The increase is calculated with the maximum r.m.s. of the learning phase after ending of the learning phase. It can be chosen between a percent or relative calculation of the threshold.
- *Alarm threshold decrease* Only required for online r.m.s. and active [classification](#). The increase is calculated with the minimum r.m.s. of the learning phase after ending of the learning phase. It can be chosen between a percent or relative calculation of the threshold.

An analysis of the alarm state of the characteristic values is done in the cycle of the storage interval. If the characteristic value has a storage interval of one minute and the diagnosis sensitivity for characteristic values in the [general](#) tab is set to 3, the alarm is generated maximal 3 minutes after the actual alarm threshold exceeding. If a short storage interval of e.g. one second is configured, it has to be considered that the Peakanalyzer has a system delay of maximal 500 ms and the alarm is generated with this maximal delay. Alternatively a number of detection per time can be set up for each characteristic value individually. For example if 5 detections per hour are configured, the alarm will be generated when the characteristic was exceeded 5 times within hour. The configured diagnosis sensitivity for characteristic values will be ignored in this case.

5.2.3.2 Process Factors



On this tab it can be configured how the formerly set process channels should be processed. The time signal, that is sampled with the set sampling frequency and generation interval, can be processed to one of the following statistical types:

- *arithmetic average*
- *quadratic average*
- *minimum*
- *maximum*
- *r.m.s*
- *peak value*
- *crest factor*
- *variance*
- *standard deviation*
- *skewness*
- *range*

By activating an alarm mode and corresponding thresholds, it is possible to receive warn or alarm notifications from the Peakalyzer if the thresholds are violated.

The following modes are available:


- *no alarm* No warn or alarm notifications are generated
- *exceedment* warn or alarm notifications are generated when the given threshold is exceeded
- *shortfall* warn or alarm notifications are generated when the given threshold shortfalls
- *out of band* warn or alarm notifications are generated when the value is out of the given band

An analysis of the alarm state of the process factors is done in the cycle of the storage interval of the corresponding process channel. If the process channel has a storage interval of one minute and the diagnosis sensitivity for process factors in the [general](#) tab is set to 3, the alarm is generated maximal 3 minutes after the actual alarm threshold exceeding. If a short storage interval of e.g. one second is configured, it has to be considered that the Peakanalyzer has a system delay of maximal 500 ms and the alarm is generated with this maximal delay. Alternatively a number of detection per time can be set up for each process factor individually. For example if 5 detections per hour are configured, the alarm will be generated when the process factor was exceeded 5 times within hour. The configured diagnosis sensitivity for process factors will be ignored in this case.

Additionally a condition can be linked to the alarm generation of a process factor. The configured minimum and maximum value of the selected process channel must be in the range. If the process channel is out of this range, no alarm will be generated.

5.2.3.3 Classification

The classification can be used to automatically learn warn and alarm thresholds for configured online characteristic values.



All configured [process channels](#) can be used for the classification. Individual class boundaries can be configured for each process information if the maximum amount of classes for this process channel is below 100. If more than 100 classes are configured, the classes are auto generated in an adjustable minimal and maximal range.

The learning time determines how long the system evaluates a specific online r.m.s. value in each class before a threshold is set. During the learning phase the global thresholds as configured in [characteristic values](#) is monitored. After the learning phase the maximum r.m.s. of the learning phase is multiplied with the threshold increase value, as configured in [characteristic values](#), to determine the learned threshold. This allows to learn and monitor the r.m.s. thresholds adopted to the actual system defined by the process information.

By setting an alarm lead time, the actual warning or alarm is only generated if the corresponding r.m.s. exceeds the threshold over the given time.

Individual classes can be explicitly excluded from the classification if the amount of classes for this process channel is below 100. In this case only the absolute configured thresholds under [characteristic values](#) are monitored. The total amount of classes over all process channels is restricted to 1,000,000.

5.2.4 Advanced Diagnosis

5.2.4.1 Drive Elements

If in the selection list of machines and drive elements a machine is selected, an overview of all sensors and their assigned drive elements is shown.

Furthermore a picture (e.g. technical drawing) can be added in the machine overview of the configuration. The sensors can be placed via Drag & Drop on this picture. This picture of the sensor positioning is also shown in the [machine overview](#) later on.

Via the button "Load machine template" a predefined [machine template](#) can be loaded into the current machine. All drive elements that are configured in the given machine template are inserted to the current machine. Only the sensor assignment of the drive elements to the available sensors must be configured.

Additionally a configured machine can be saved in the pool of machine templates by pressing the button "Save as machine template". This template is then available in the menu point [machine templates](#) and can be used by all other Peakalyzer.

Add Drive Element

To add a drive element to a machine, the drive element type must first be selected from the drop down list. The following drive elements are available:

- [Shaft](#)
- [Drive Shaft](#)
- [Clutch](#)
- [Gear Drive](#)
- [Belt Gearing](#)
- [Planetary Gear](#)
- [Rolling Bearing](#)
- [Three-Phase Motor](#)
- [Speed ratio](#)
- [Steady Frequency in FSP](#)
- [Steady Frequency in HKFSP](#)
- [Steady Order in OSP](#)
- [Steady Order in HKOSP](#)

For each drive element the following parameters must be set:

- *Name of drive element* An arbitrary name for that drive element
- *Tolerance* relative width of the tolerance band for the diagnosis. Each drive element already has useful default settings.

For some drive elements additional kinematic parameters must be set that can be obtained from the manufacturer or special databases.

After setting all kinematic parameters, the drive element can be assigned to multiple sensors that should monitor this drive element. This can be made with an automatic determination of the measurement time. Thus an optimal measurement time is calculated by the given speed range (see [speed channels](#)) and the given kinematic parameters. If multiple drive elements are assigned to one sensor, it can lead to a second measurement time for this sensor.

If the automatic determined measurement time does not meet all requirements, it can be adopted manually. This counts for all drive elements. In this case it must be ensured by the user that all diagnosis attributes of the drive elements can be found in the spectra.

Delete Drive Element

A drive element can be deleted from the configuration by selecting it from the list and clicking the button "Delete Drive Element". Thus all assigned sensors will also be unlinked from this drive element and the measurement time is recalculated for the former assigned sensors.

Copy Drive Element

If multiple identically constructed machines should be monitored by the Peakalyzer, drive elements can be copied from one machine to another. This can be done by selecting and right clicking the relevant drive element in the list to open the context menu. Then by choosing the menu Copy the drive element is copied

into the clipboard. It can be inserted to another machine by opening the context menu of the new machine and clicking Insert. Thus all sensor assignments are deleted for the new drive element.

Shaft

Exactly one shaft in the system must be configured as reference shaft. This is also the shaft where the speed is measured. It has always the transmission of 1. The transmission of all other shafts in the machine are in relation to this reference shaft.

Normally a tolerance of 0.1 % is suitable.

In the analysis it is searched for loose particles and unbalance on the configured shafts.

Drive Shaft

The drive shaft is also a shaft which can be used as reference shaft.

Normally a tolerance of 0.1 % is suitable.

In the analysis it is searched for loose particles, link damage and unbalance on the configured shafts.

Clutch

A clutch can be configured as fixed connection or as shifting clutch between two shaft. Therefore the input and output shaft must be set to one shaft of the already configured shafts. If this clutch is fixed the option coupled has to be set to yes. If the clutch is decoupled due to gear switching the option must be set as free parameter.

Normally a tolerance of 0.1 % is suitable.

In the analysis it is searched for misalignment on the configured clutches.

Gear Drive

The gear drive describes a spur gear and bevel gear. It must be chosen a shaft for the pinion and wheel respectively. It has to be set whether the pinion and wheel are coupled with the shaft or whether the coupling between pinion and shaft or wheel and shaft is decoupled due to gear switching. Furthermore the number of teeth for the pinion and wheel has to be entered. Additionally the parameter internal toothing can be set if one side of the gear drive has an internal toothing. In this case the rotational direction of the outgoing shaft is not reversed.

Normally a tolerance of 0.1 % is suitable.

In the analysis it is searched for revolving deviation of flank shapes and local deviation of flank shapes at the pinion and wheel on the configured gear drives.

Belt Gearing

For the belt gearing the shaft of the driven and driving wheel. It has to be configured whether the driven and driving wheel is fixed coupled with the shaft or whether the connection is modified due to gear switching. Furthermore the diameter of the driven and driving wheel as well as the length of the belt must be defined.

Normally a tolerance of 0.1 % is suitable.

In the analysis it is searched for local irregularities of the belt on the configured belt gearings.

Planetary Gear

The planetary gear covers planetary gears with single planets (in contrast to stage planets). The number of planets, number of tooth of the planets, sun and annulus must be configured. Furthermore the shafts must be selected for the annulus, sun and planetary carrier.

The mode of the planetary gear must be configured. One of the following combinations can be used:

- sun and planetary carrier rotate and annulus is fixed

- sun and annulus rotate and planetary carrier is fixed
- planetary carrier and annulus rotate and sun is fixed
- all shafts rotate


The modes can also be set as free parameter if the state changes due to gear shifting.

Normally a tolerance of 0.1 % is suitable.

In the analysis it is searched for local irregularities of the sun, annulus and planets as well as for revolving deviation of flank shapes on the configured planetary gears.

Rolling Bearing

For the rolling bearing the kinematic parameters must be configured. These are the rotational cage order, the ball spin order, the double ball spin order and the ball pass order of the outer and inner ring. These data can be obtained from the manufacturer of the rolling bearing. The input of the rotational orders can be done with respect to order 1 or with respect to the relative speed of the rolling bearing. Alternatively a bearing type can be chosen from the [bearing database](#). The data for the rotational orders are then taken from the bearing database and can not be changed in the bearing itself.



Furthermore the shafts for the outer and inner ring must be chosen. If one of these is fixed the shaft can be left empty.

If the rolling bearing is configured as planetary rolling bearing no shafts must be set.

Normally a tolerance of 1 % is suitable to compensate slippage of the rolling bearing.

In the analysis it is searched for outer and inner ring damage, cage damage and rolling element damage on the configured rolling bearings.

Three-Phase Motor

For the three-phase motor the net frequency must be configured.

Normally a tolerance of 0.1 % is suitable.

In the analysis it is searched for magnetic imbalance on the configured three-phase motors.

Speed ratio

The drive element speed ratio can be used to dynamically adjust the ratio of an input and output shaft. A process channel must be set, that describes the speed ratio between these two shafts. For example the actual speed of the two shafts can be measured with a speed sensor and the calculated to a speed ratio with the [virtual process channels](#). To validate the remaining drive elements in the configuration, a speed ratio can be entered that is only used in the configuration.

During a measurement the speed ratio should be relatively constant since the average value of the speed ratio is used that was measured during the whole measurement time. The maximal percent deviation can be entered for this process channel in the [diagnosis condition](#) section.

A monitoring of this drive elements via sensors is not possible.


Steady Frequency

The elements steady frequency and steady frequency envelope can be used to monitor individual frequencies in the frequency spectrum and envelope frequency spectrum respectively. The frequency must be configured.

Steady Order

The elements steady order and steady order envelope can be used to monitor individual orders in the order spectrum and envelope order spectrum respectively. The order must be configured.

5.2.4.2 Diagnosis Conditions



There can be two diagnosis conditions defined for each machine that is monitored by the Peakalyzer. An analysis of the measurement data is only done if one of these diagnosis conditions is fulfilled. Furthermore the diagnosis condition is used as a precondition for the start of the measurement.

The following common parameters must be set:

- *conditional start time* Only if the conditions are fulfilled for the given period a measurement can start
- *unconditional start time* If the conditions are not fulfilled for the given period the measurement is started anyway. This is required to ensure a regular operational state of the diagnosis system. This value must be larger than the conditional start time
- *max. speed change* The maximal speed change that is allowed during one measurement. Useful values are up to 20% of maximal speed change.

One diagnosis condition can consist of the following conditions:


- *Name* An arbitrary description of the diagnosis condition that can be used as filter criteria in the analysis later on
- *Speed min/max/rotating direction* The maximal and minimal speed. The speed range must be fulfilled the complete conditional start time period to trigger a measurement. After the measurement is finished it is also checked whether the speed was in the range during the measurement time of the corresponding speed channel. If the connected speed sensor has also an information about the rotating direction via its A and B lines, it is also possible to use the rotating direction as condition. If the speed sensor does not have this information a forward rotating machine or engine is assumed.
- *Process range min/max* A channel that is configured in the process channels can be selected. A minimal and maximal value must be set that should apply to this diagnosis condition. A measurement is only started if the given process range is fulfilled the whole conditional start time period. After the measurement is finished it is also checked whether the process conditions were fulfilled during the measurement time.
- *Digital input as trigger* If the Peakalyzer has digital inputs, these can be used to directly trigger the start of a measurement. The conditional start time will be ignored in this case and the measurement will

start immediately. The speed and process channel ranges are checked at then end of the measurement to ensure fulfilled conditions during the whole measurement time.

5.2.5 Communication

5.2.5.1 Bus Outputs

If the Peakalyzer has a Profibus-Slave, the Profibus can be configured for output information of characteristic values, process factors and kinematic alarms of drive elements. These information can be for example displayed in a process control system.




The data structure of the telegram can be defined by the configured characteristic values and process factors. There will be permanently all data in the telegram available. If a new value for one field is available on the Peakalyzer, the telegram content will be updated accordingly. The transmitted values are multiplied with a scale factor to configure the desired accuracy for Integer formats. Additionally multiple status WORD can be added to the telegram where individual warn and alarm threshold exceeding of characteristic values, process factors or drive elements can be configured. The telegram of the above depicted configuration will have the following structure:

Byte	Data type	Description
1-4	32-Bit Floating Point	Sensor5: Minimum
5-8	32-Bit Floating Point	Sensor5: Maximum
9-12	32-Bit Floating Point	Sensor6: Minimum
13-16	32-Bit Floating Point	Sensor6: Maximum
17-18	16-Bit Integer	DMS: Minimum
19-20	16-Bit Integer	DMS: Maximum
21-22	16-Bit Integer	DMS: r.m.s

23-24	16-Bit Integer	DMS: peak value
25-26	16-Bit Integer	DMS: variance
27-30	32-Bit Integer	DMS: standard deviation
31-34	32-Bit Integer	DMS: instantaneous value
35-38	32-Bit Integer	DZ2_Profibus_Int16: Minimum
39-42	32-Bit Integer	DZ2_Profibus_Int16: Maximum
43-46	32-Bit Integer	DZ2_Profibus_Int16: arithmetic average
47-50	32-Bit Integer	Sensor1: r.m.s. of vibration velocity
51-54	32-Bit Integer	Sensor1: r.m.s. of vibration acceleration
55-58	32-Bit Integer	Sensor1: r.m.s. of vibration acceleration envelope
59-60	16-Bit Integer	Status WORD 1
61-62	16-Bit Integer	Status WORD 2

The telegram is set according to this configuration to a size of 31 WORD. The Profibus master must be configured accordingly. It has to be note that the data is send in big endian format. The last two WORD contain status information of warn and alarm threshold exceeding. Each individual bit can be configured with a exceeding. An example configuration of Status WORD 1 is depicted in the following picture:




Profibus

To use the Profibus for input channels the check for "Activate Input" must be set. Furthermore the Profibus-Slave-Address must be set that is agreed with the Profibus-Master. Afterwards the configuration of the input channels is done as described in [Bus Outputs](#).

After transmitting the configuration a 18-WORD telegram is added to the Profibus-Slave in the single mode. The data is always transmitted in big endian format. In the multi mode the telegram size depends on the number and type of configured outputs. The telegram must be configured equally on the corresponding

Profibus-Master. In the program directory of the Peakalyzer the GSD file of the Profibus-Slave can be found which maybe is needed for configuring the Profibus-Master.


Profinet



To use the Profinet-Device for output information, the check "Activate Output" must be set. The MAC-Address of the Profinet-Device is provided on this site for the correct configuration of the Profinet-Device. Furthermore the last 4 numbers of the Profinet station name can be modified to avoid name conflicts with other devices. Afterwards the configuration of the outputs is done as described in [Bus Outputs](#).

After transmitting the configuration the telegram with the defined size is applied on the Peakalyzer. For the single mode the telegram size is 32 WORD where only the first 18 WORD are used. In the multi mode the telegram size of the Profinet-Device is according to the configured outputs and always round up to the next power of two. Thus there are only telegrams of the size 1, 2, 4, 8, 16, 32 or 64 WORD. The data is always transmitted in Big Endian format. The telegram structure must be configured on the Profinet-Controller in the same manner. The GSDML file of the Profinet-Device that may be necessary for the configuration of the Profinet-Controller can be found in the program directory of the Peakalyzer Manager.

5.2.5.2 Digital Outputs



Digital outputs can be used to signalize threshold exceedments of [process factors](#) or [characteristic values](#). Up to 2 digital outputs can be configured for each warn and alarm threshold. If one digital output is configured for multiple process factors or characteristic values, the digital output serves as sum alarm. The digital output is set if one of the configured characteristic values or process factor is signalized.

The following settings must be set:

Datatype: The [process factor](#) or [characteristic value](#) that should be signalized via a digital output


Warn contact 1: The digital output that is set if the warn threshold is exceeded.

Warn contact 2: The digital output that is set if the warn threshold is exceeded.

Alarm contact 1: The digital output that is set if the alarm threshold is exceeded.

Alarm contact 2: The digital output that is set if the alarm threshold is exceeded.

5.2.5.3 Current Outputs



Current outputs can be used to output a process factor or a characteristic value as analogue signal (0 to 20 mA). If a new value of the data type is available it is transferred to the analogue value and output to the corresponding channels. This information can be used to display the values in a process control system. Only one data type can be configured per current output. The following settings must be configured:

Data type: the process factor or characteristic value that should be outputted

Current output: the channel for the configured data type

Sensitivity: the value of the data type is factorized with this value to get the analogue value


Offset: this values is subtracted from the data type value before the sensitivity is applied

Measurement range: the resulting output range for the configured data type

In the above example the r.m.s of vibration velocity of one sensor is configured that 4 mA corresponds to 0 mm/s and 20 mA corresponds to 15 mm/s.

5.2.5.4 Remote

The Peakalyzer can be configured for automatically call a server in a cyclic manor or if an alarm is generated. This is done on the tab Remote.




Up to 5 server can be configured that are called by the Peakalyzer. For each entry the following settings must be made:

- IP-Address or DNS server name of the server
- TCP-Port that is configured on Server
- Dial-In interval in which the server should be called
- Dial-In interval to the server if a communication error occurs
- Dial-In interval from .. to the time of the day where the Peakalyzer calls the server

It must be ensured that the given server has installed the Peakalyzer Manager and the service is configured with the correct remote port. The configuration of the service can be found in [cyclic download](#). Furthermore it must be ensured that the connection is not blocked by any firewall.

5.2.5.5 E-Mail

The Peakalyzer can be configured to automatically send E-Mails if an alarm occurs.



To enable this function, the option "Activate E-Mail" must be set first. Afterwards the sender and recipient must be configured by the following parameter:


- *Sender* The sender of the E-Mail that should be used for the sending
- *SMTP-Server* The mail server that should be used for sending the E-Mail
- *SMTP-Port* The port of the mail server
- *Username* The username to login to the SMTP-Server. This is usually the E-Mail address on most providers
- *Password* the password to login to the SMTP-Server
- *Recipient* The recipient that should receive the E-Mail
- *Language* The language of the E-Mail. It can be chosen between German and English
- *Subject prefix* This text will be set before the subject of the E-Mail. This can be used to automatically filter the E-Mails to categories.

Finally the categories where an alarm should be send can be configured. An arbitrary combination of advanced diagnosis, characteristic values and process factors can be chosen.

After the configuration is transmitted, the Peakalyzer will automatically send an E-Mail to the recipient if an alarm occurs. The E-Mail will contain an information about the current alarm and also a list with all not acknowledged alarms that are present on the Peakalyzer. The alarm suppression time that is configured in the [storage management](#) will be respected. Thus the same alarm will only notified again if the given time is elapsed.

A test E-Mail can be send from the Peakalyzer via the button "Send Test E-Mail" to verify the above configuration. If an error occurred a corresponding message is displayed.

5.2.6 Storage Management



On this tab, it can be configured how often and which type of measurement data should be saved. An asset history of the relevant measurement data will be saved in the set intervals. Individual intervals can be configured for the following measurement and analysis data:

- *Diagnostic attributes* Amplitude, order and significance are saved for each damage pattern for each monitored drive element.
- *Characteristic values* the characteristic values that are configured in the tab characteristic values.
- *Spectra* the frequency, envelope frequency, order and envelope order spectra that were calculated during the analysis
- *Time Signals* the reduced time and envelope time signals that were calculated during the measurement
- *Original Time Signals* the 50 kHz raw time signals, that were measured. Saving of raw time signals can lead to extensive memory usage on the Peakalyzer.
- *Process Factor* the high resolution (up to 1 kHz) signals of the process channels
- *Characteristic Values* the high resolution online characteristic value (up to 1 kHz)

Additionally the data types that should be saved in case of an alarm can be configured. The following types are available:

- *Diagnostic attributes*
- *Characteristic values*
- *Spectra*
- *Time Signals*


Furthermore it can be configured how long an existing alarm should be suppressed. A specific alarm notification is not written to the logbook until the set time is elapsed.

The Peakalyzer automatically deletes measurement and analysis data that is older than the set duration of data storage. If the Peakalyzer is not available during the given time, the measurement and analysis data are lost.

5.3 Service Measurement

The service measurement can be opened on the menu Analysis → Service Measure or on the navigation bar at the bottom. This functionality is only available if the view of the Peakalyzer Manager is in the measurement devices mode and a Peakalyzer is selected in the left tree view.

The service measurement allows to measure up to 8 channels in parallel on the Peakalyzer. It has to be considered that the measurement is done with the maximum sampling frequency. Therefore a stable and good connection via LAN must be established to the Peakalyzer. On the right side the desired sensors can be selected. The sensor settings from the current monitoring configuration are used for the service measurement. The setting of the measurement time is independent from the monitoring configuration and can be adjusted in steps of one second. By clicking the button "Start Measure" the currently running monitoring configuration is stopped if necessary and the service measurement is initialized. The acquired measurement data are visualized in the curve window. The service measurement can be stopped at any time by clicking "Stop Measure". By clicking on "Save Measure" all measured sensors will be saved in the database of the Peakalyzer. Additionally are frequency and envelope frequency spectra calculated for the sensors of the vibration inputs. If furthermore the corresponding reference speed channel is measured, order and envelope order spectra are calculated. These data can be viewed and analyzed in the [analysis](#) section. They can also be exported from there. After the service measurement is finished, it will be asked whether the regular monitoring configuration should be restarted.



5.4 Data Management

All data that is generated on the Peakalyzer as well as the configuration of the Peakalyzer will be saved in a data base per Peakalyzer on the configured SQL-Server.

During the installation of the Peakalyzer Manager a Windows background service was installed. This service downloads the data of one or multiple Peakalyzers and adds it into the database. This background service, once configured, runs autarkic. Therefore it is not required to open the Peakalyzer Manager or even have an active windows user logged in to download measurement data from the Peakalyzers.


If the Peakalyzer or a machine is selected in the left tree view in the Peakalyzer Manager, the button Update can be pressed in the navigation bar at the bottom to initiate the update process for measurement data and configurations.

During the communication with a Peakalyzer the following actions will take place:

- Synchronization of the configurations of the Peakalyzer and the local database
- Acknowledgment and reset of alarms that were handled via the Peakalyzer Manager
- Querying of new alarm notifications
- Querying of sensor information (broken wire detection, current r.m.s. values, current speed values, current process channel information)
- Closing of the current measurement directory if there is any alarm
- Download of measurement data
- Insertion of all measurement data in the local database

5.4.1 Cyclic Download

The computer, that have the Peakalyzer Manager installed, can also be configured to cyclically connect to a selection of Peakanalyzers and download the corresponding measurement data. This can be configured in the menu Service → Configuration.



Two time frames and one redial interval can be configured where the computer tries to connect to the Peakanalyzers and download the measurement data. To activate a Peakalyzer the column active must be set to local on the corresponding Peakalyzer. If the Peakalyzer can respond to a Ping, the check box allow ping should be enabled. With this option enabled, the connection will be only established if a Ping was successful.


Furthermore the login data for the Peakalyzer must be given to automatically download the measurement data. These can be set via the properties of the Peakalyzer.

An overview of the resource utilization and tasks of the configured service is shown in the menu Service → Status. In this overview the following information of the service is summarized:

- active and past action for each Peakalyzer
- current progress of the active action for each Peakalyzer
- Usage of RAM and CPU of the service

5.4.2 Backup Strategies

All measurement data and configurations of one Peakalyzer can be exported. Thus measurement data and configurations can be transferred from one Peakalyzer Manager to another with a different database server connected. To initiate the export the Peakalyzer must be selected on the left tree view. In the menu Diagnosis System → Export a folder must be selected where the backup will be saved. Furthermore a timespan must be set when the data was created.



Afterwards the backup can be transferred to another PC with Peakalyzer Manager installed. On this target system the backup can be imported via the Peakalyzer Manager in the menu Diagnosis System → Import. After the backup process finished, the measurement data and configurations are available by choosing the Peakalyzer in the left tree view.

5.4.3 Download Data

Measurement data and configurations can also be downloaded from a Peakalyzer without the program Peakalyzer Manager. So it is possible to save the measurement data and configurations initially on a removable media and add them later to the Peakalyzer Manager. To download the data from the Peakalyzer an active LAN connection to the Peakalyzer must exist. Afterwards a connection via a FTP program or the Windows Explorer can be established as follows:

URL: ftp://IP-Address:Port
 User: gfm
 Password: gfm

The IP-Address of the Peakalyzer must be known beforehand. The default port for the FTP-Access is 8523. If the port was modified, the set port +2 must be used as FTP-Port.

If the Peakalyzer has the following network settings:

IP-Address: 10.10.210.210
 Port: 6000 - 6004

For FTP access the following URL must be typed in: ftp://10.10.210.210:6002

In the FTP root directory exists a Data and a Konfig directory. These can be saved via the FTP access on a notebook or removable media. It is recommended to download the complete directories.

Via the program Peakalyzer Manager the measurement data and configurations can be added to the database of the corresponding Peakalyzer. The Peakalyzer must be selected on the left tree view. By clicking the menu point Data → "Load from directory", the directory with the Data and Konfig can be chosen. The measurement data and configurations will be inserted in the database for the Peakalyzer and are subsequently available in the analysis in the navigation bar at the bottom of the Peakalyzer Manager.

5.5 Logbook

The logbook contains all information that reproduce the operational state of the Peakalyzer. These logbook notifications are divided in the following categories and subcategories and can also be filtered accordingly:

- Alerting
 - vibration diagnosis
 - characteristic values
 - process factors
 - threshold changes
- Device states
- Diagnosis states
- Data storage
- User access

Furthermore the following criteria can be used to additionally restrict the displayed information:

- *Machine* If the logbook is called from a Peakalyzer with multiple machines configured, the logbook entries can be filtered on the selected machine. If the logbook is called directly from a machine, this option is disabled.
- *Sensor* If a logbook entry is related to a specific sensor (e.g. asset histories or alarm notifications), the displayed messages can be filtered to the selected sensor. If a machine was used as a filter criteria, the list of available sensors is reduced to the sensors that monitor that specific machine.
- *Drive element* If a logbook entry has a reference to a drive element (e.g. alarm notifications), the displayed messages can be filtered to the selected drive element.
- *Time frame from/to* This criteria allows to filter the displayed logbook entry according to the set time frame.

The screenshot shows the Peakalyzer Manager interface for machine CX-13D340. The top menu includes Diagnosis System, Configuration, Data, Analysis, View, Templates, Service, and Extras. The left sidebar shows a tree view of categories: Alerting (expanded), Vibration diagnosis, Characteristic values, Process factors, Threshold changes, Device states, Diagnosis states, Data storage, and User access. The main area contains filter fields for Machine, Sensor, Drive element, and Time frame (from: 10/25/2017, to: 1/25/2018). Below the filters is a table of logbook entries.

Time	Category	Notification
24.01.2018 15:14:20	Alerting	local irregularity pinion at gear drive Verzahnung measured with Sensor2 (S, Z, M, K). DVS: 3.56
24.01.2018 11:59:18	Alerting	local irregularity sun at planetary gear Planetenstufe measured with Sensor3 (S, Z, M, K). DVS: 2.75
24.01.2018 11:59:18	Alerting	inner ring damage at rolling bearing Lager Sonne SKF 23044c measured with Sensor4 (S, Z, M, K). DVS: 4.68
24.01.2018 11:52:03	Alerting	inner ring damage at rolling bearing Motorlager FAG 6330 measured with Sensor1 (S, Z, M, K). DVS: 3.32
24.01.2018 11:52:03	Alerting	revolving toothing damage at gear drive Verzahnung measured with Sensor1 (S, Z, M, K). DVS: 17.54
24.01.2018 10:38:28	Alerting	loose particles at shaft Antriebswelle measured with RG_MotorA (S, Z, M, K). DVS: 10.76
24.01.2018 10:38:28	Alerting	unbalance at shaft Antriebswelle measured with RG_MotorA (S, Z, M, K). DVS: 8.17
24.01.2018 10:38:28	Alerting	local irregularity belt at belt gearing Riemenantriebe measured with RG_MotorA (S, Z, M, K). DVS: 14.77
24.01.2018 10:38:28	Alerting	rolling element damage (s) at rolling bearing Motorlager A measured with RG_MotorA (S, Z, M, K). DVS: 17.65
24.01.2018 10:38:28	Alerting	rolling element damage (s) at rolling bearing Motorlager A measured with RG_MotorA (S, Z, M, K). DVS: 11.41
24.01.2018 10:38:28	Alerting	rolling element damage (s) at rolling bearing Motorlager A measured with RG_MotorA (S, Z, M, K). DVS: 16.12
24.01.2018 10:38:28	Alerting	magnetical imbalance at three-phase motor Motor measured with RG_MotorA (S, Z, M, K). DVS: 20.27
24.01.2018 10:38:28	Alerting	outer ring damage at rolling bearing Maschine Lager A measured with RG_MotorB (S, Z, M, K). DVS: 1.36
24.01.2018 10:38:28	Alerting	cage damage at rolling bearing Maschine Lager A measured with RG_MotorB (S, Z, M, K). DVS: 12.88
24.01.2018 10:38:28	Alerting	outer ring damage at rolling bearing Maschine Lager B measured with RG_MotorB (S, Z, M, K). DVS: 1.36
24.01.2018 10:25:47	Alerting	local irregularity annulus at planetary gear Planetenstufe measured with Sensor5 (S, Z, M, K). DVS: 2.67
24.01.2018 10:22:00	Alerting	inner ring damage at rolling bearing Motorlager A measured with BHKW_MotorB (S, Z, M, K). DVS: 3.97
24.01.2018 10:22:00	Alerting	outer ring damage at rolling bearing Motorlager A measured with BHKW_MotorB (S, Z, M, K). DVS: 2.29
24.01.2018 10:22:00	Alerting	outer ring damage at rolling bearing Motorlager A measured with BHKW_MotorB (S, Z, M, K). DVS: 4.19
24.01.2018 10:22:00	Alerting	outer ring damage at rolling bearing Motorlager B measured with BHKW_MotorB (S, Z, M, K). DVS: 2.29
24.01.2018 10:22:00	Alerting	outer ring damage at rolling bearing Motorlager B measured with BHKW_MotorB (S, Z, M, K). DVS: 4.19
24.01.2018 10:22:00	Alerting	unbalance at shaft Antriebswelle measured with BHKW_MotorA (S, Z, M, K). DVS: 6.72
24.01.2018 10:22:00	Alerting	misalignment at clutch Kupplung measured with BHKW_MotorA (S, Z, M, K). DVS: 6.72
24.01.2018 10:22:00	Alerting	inner ring damage at rolling bearing Motorlager A measured with BHKW_MotorA (S, Z, M, K). DVS: 1.74

At the bottom of the window, there are buttons for Properties, Configure, Service Measure, Update, Alarm View, and Analysis.

5.5.1 Alerting

The logbook category alerting contains all messages that are generated due to threshold violations. By selecting a specific row and clicking "Show measurement data" the Peakalyzer opens the analysis view and displays the related measurement data. The alarm notifications are divided in the following 3 subcategories:

- vibration diagnosis This subcategory contains concrete plain text messages about found irregularities at one drive element. Such a message is for example: "outer ring damage at rolling bearing Motor A measured with Sensor2 (S, Z, M, K). DVS: 1,86".
- characteristic values This subcategory contains alarm and warn threshold exceeding of configured characteristic values. Such a message is for example: "Characteristic value alarm at Sensor2: 12.3 mm/s"
- process factors This subcategory contains alarm and warn threshold exceedments or shortfalls for configured process factors. Such a message is for example: "Process factor alarm at Wind: arithmetic average: 10.00 m/s".

Furthermore the subcategory threshold changes contains all messages that led to an increase or reset of alarm thresholds, initiate by an alarm handling of an user.

5.5.2 Device states

The category device states contains notifications of the operational state of the Peakalyzer. Concrete are the following messages displayed:

- check of over-voltage protection
- start of the monitoring
- stop of the monitoring
- system reboot
- hardware check
- power failure detected

5.5.3 Diagnosis states

The category diagnosis state summarizes all notification of the fulfilled or not fulfilled diagnosis ranges. Thus it can be reproduced which condition was fulfilled at a specific time and therefore an analysis of the measurement data was done. Concrete are the following messages displayed:

- diagnosis range 1 fulfilled at machine
- diagnosis criteria not fulfilled at machine

5.5.4 Data storage

This category contains all messages related to saved measurement data. The time intervals were configured in the [Storage Management](#) section of the configuration. Such a message is for example: "Save asset history at Sensor4 (S, Z, M, K)". The abbreviations describe the data that are saved due to the asset history and have the following meaning:

- S frequency, envelope frequency, order and envelope order spectra
- Z time, envelope time and speed signals
- M diagnostic attributes for all drive elements that are monitored by the current sensor
- K characteristic values that are configured at the current sensor

5.5.5 User access

The category user access contains messages that are related to an user interaction with the Peakalyzer. Concrete are the following messages displayed:

- user logged in
- configuration transmitted by user
- alarms acknowledged by user
- alarms reset by user

- data downloaded by user

5.6 Status Messages

The status messages provide information about the state of one Peakalyzer. After the first start of the Peakalyzer Manager the status messages are empty.

To view the status messages the following steps must be followed:


- The Peakalyzer must be selected
- The Peakalyzer must have a valid configuration
- The Peakalyzer must be updated at least once


The update can be done via the following two options. The update can be done automatically via the [Cyclic download](#) or manually at the bottom via the button "Update".

If the preconditions are met, the status messages can be displayed for the corresponding Peakalyzer. The status messages are displayed by selecting the Peakalyzer in the tree view.

One of the displayed categories are the status notifications. Initially only warnings are shown in the status messages. These are messages that crossed configured thresholds.

The button with the black point must be pressed to view all status messages. The black point then turns into a blue point.






5.6.1 Threshold Settings

The threshold settings allow to adjust the messages individually. In the menu Service → Configuration must be selected to open the threshold settings. In the last column of the selected Peakalyzer is a button that opens when you click a menu. In this menu, there is another button "Adjust" is clicked this, a window open, where the thresholds can be adjusted appears.

In the window service configuration it is also possible to adjust the timespan. The timespan is required for some statistics that are displayed in the status messages. The timespan is meant backwards from today over the given timespan.




In the window threshold settings individual thresholds can be set. Initially some thresholds are already set. By clicking the button "Add threshold" the new thresholds can be configured.

Threshold settings for: CX-13D340

Activ	State Message	Threshold	Unity
<input checked="" type="checkbox"/>	Last monitoring status	Inactiv	
<input checked="" type="checkbox"/>	Last connection	03 : 00 dd : hh	
<input type="checkbox"/>	Last alarm: Message	Kinematic	
<input type="checkbox"/>	Last alarm: Date	00 : 00 dd : hh	
<input type="checkbox"/>	Last alarmraise	00 : 00 dd : hh	
<input checked="" type="checkbox"/>	Last order spectrum: Blockheizkraftwerk	05 : 00 dd : hh	
<input checked="" type="checkbox"/>	Last order spectrum: Demomaschine	05 : 00 dd : hh	
<input checked="" type="checkbox"/>	Last order spectrum: Riememgetriebe	05 : 00 dd : hh	
<input type="checkbox"/>	Last speed in a valid evaluation range: Blockheizkraftwerk	0	
<input type="checkbox"/>	Last speed in a valid evaluation range: Demomaschine	0	
<input type="checkbox"/>	Last speed in a valid evaluation range: Riememgetriebe	0	
<input type="checkbox"/>	Last restart of the Peakalyzer: Reason	Unknown	
<input type="checkbox"/>	Last restart of the Peakalyzer: Time	00 : 00 dd : hh	
<input type="checkbox"/>	Last restart of the Peakalyzer: Quantity	0	
<input type="checkbox"/>	Last start of the monitoring	00 : 00 dd : hh	
<input type="checkbox"/>	Last stop of the monitoring	00 : 00 dd : hh	
<input type="checkbox"/>	Last service measure	00 : 00 dd : hh	
<input type="checkbox"/>	Last firmware update	00 : 00 dd : hh	
<input type="checkbox"/>	Last configuration transfer	00 : 00 dd : hh	
<input type="checkbox"/>	Last network change	00 : 00 dd : hh	
<input type="checkbox"/>	Last Peakalyzer version		
<input type="checkbox"/>	Hard drive storage: Overall	0	Byte
<input checked="" type="checkbox"/>	Hard drive storage: Free	1	GByte
<input type="checkbox"/>	Ping answertime: Minimum	0	ms

Save Cancel

In the column "Status message" it can be chosen between the various available messages. Each message requires a context dependent threshold. Some of these messages also require a unit in the column "Unit". A detailed description can be found in the chapter [Status Messages Description](#).



5.6.2 Status Messages Description

The following table displays all available status messages in the Peakalyzer Manager

Status message	Description	Threshold Parameter
Last monitoring status	shows the status whether the monitoring of the Peakalyzer was active or inactive at the last update.	Active/Inactive
Last connection	shows the date of the last connection to the Peakalyzer	Timespan: Days::Hours (dd:hh)
Last alarm: Message	shows the type of the last alarm	Kinematic/Characteristic Value/Process
Last alarm: Date	shows the date of the last alarm	Timespan: Days::Hours (dd:hh)
Last alarmraise	shows the date of the last alarm threshold increase by an user	Timespan: Days::Hours (dd:hh)
Last order spectrum (machine based)	shows the date of the last order spectrum on the Peakalyzer for the monitored machine	Timespan: Days::Hours (dd:hh)
Last speed in a valid evaluation range (machine based)	shows the date of the last valid speed value during the last analysis on the Peakalyzer	0.0 - 100000.0 in 1/min
Last start of the monitoring	shows the date of the last start of the monitoring	Timespan: Days::Hours (dd:hh)
Last stop of the monitoring	shows the date of the last stop of the monitoring	Timespan: Days::Hours (dd:hh)

Last service measure	shows the date of the last service measurement	Timespan: Days::Hours (dd:hh)
Last firmware update	shows the date of the last firmware update	Timespan: Days::Hours (dd:hh)
Last configuration transfer	shows the date of the last transmitted configuration	Timespan: Days::Hours (dd:hh)
Last network change	shows the date of the last change of the IP address	Timespan: Days::Hours (dd:hh)
Hard drive storage: Free	shows the total size of the hard disk in the Peakalyzer	0 Byte - 100000 TByte
Hard drive storage: Overall	shows the free size of the hard disk in the Peakalyzer	0 Byte - 100000 TByte
Last restart of the Peakalyzer: Reason	shows the reason of the last restart of the Peakalyzer	by user/unknown/Firmware update/Rescan boxes
Last restart of the Peakalyzer: Time	shows the date of the last restart of the Peakalyzer	Timespan: Days::Hours (dd:hh)
Last restart of the Peakalyzer: Quantity	show the number of restarts of the Peakalyzer during a timespan. The timespan can be configured in the Cyclic Download. If the value is changed the Peakalyzer Manager must update the Peakalyzer.	0 - 100000
Ping answertime: Minimum	shows the minimum ping round trip time to the Peakalyzer. If the value is 0 ms, the ping was deactivated in Cyclic Download.	0 - 100000 in ms
Ping answertime: Maximum	shows the maximum ping round trip time to the Peakalyzer. If the value is 0 ms, the ping was deactivated in Cyclic Download.	0 - 100000 in ms
Ping answertime: Average	shows the average ping round trip time to the Peakalyzer during a timespan. The timespan can be configured in the Cyclic Download. If the value is changed the Peakalyzer Manager must update the Peakalyzer. If the value is 0 ms, the ping was deactivated in Cyclic Download.	0 - 100000 in ms
Ping packages: Receive	shows the amount of successful pings. If this value is 0 the ping may be deactivated in the Cyclic Download. The counter is only for the current day.	0 - 100000
Ping packages: Lost	shows the amount of failed pings. If this value is greater or equal 1 and the amount of successful pings is 0, a connection problem exists to the Peakalyzer. The counter is only for the current day.	0 - 100000
Connection Status: Successful	shows the amount of successful connections to the Peakalyzer during a timespan. If this value is 0 the Peakalyzer Manager have not yet received any data from the Peakalyzer or a connection problem occurred. The timespan can be configured in the Cyclic Download. If the value is changed the Peakalyzer Manager must update the Peakalyzer.	0 - 100000

Connection Status: Broken	show the amount of interrupted connections to the Peakalyzer during a timespan. This value should be 0. Otherwise the connection may be very slow. The timespan can be configured in the Cyclic Download. If the value is changed the Peakalyzer Manager must update the Peakalyzer.	0 - 100000
Connection Status: Failed	shows the amount of failed connections to the Peakalyzer during a timespan. This value should be 0. Otherwise connections problems occurred. The timespan can be configured in the Cyclic Download. If the value is changed the Peakalyzer Manager must update the Peakalyzer.	0 - 100000
Connect Time: Last	shows the last connection time to the Peakalyzer.	0 - 100000 in ms
Connect Time: Total	shows the total connection time to the Peakalyzer during a timespan. The timespan can be configured in the Cyclic Download. If the value is changed the Peakalyzer Manager must update the Peakalyzer.	0 - 100000 in ms
Connect Time: Average	shows the average connection time to the Peakalyzer during a timespan. The timespan can be configured in the Cyclic Download. If the value is changed the Peakalyzer Manager must update the Peakalyzer.	0 - 100000 in ms
Download Speed: Last	shows the last download speed	0 Byte/s - 100000 TByte/s
Download Speed: Average	show the average download speed during a timespan. The timespan can be configured in the Cyclic Download. If the value is changed the Peakalyzer Manager must update the Peakalyzer.	0 Byte/s - 100000 TByte/s
Amount of data: Last	shows the last downloaded data amount.	0 Byte/s - 100000 TByte
Amount of data: Total	shows the total downloaded data amount during a timespan. The timespan can be configured in the Cyclic Download. If the value is changed the Peakalyzer Manager must update the Peakalyzer.	0 Byte/s - 100000 TByte
Amount of data: Average	shows the average downloaded data amount during a timespan. The timespan can be configured in the Cyclic Download. If the value is changed the Peakalyzer Manager must update the Peakalyzer.	0 Byte/s - 100000 TByte
Amount of data: actual Month	shows the downloaded data amount during the current month	0 Byte/s - 100000 TByte

6 PeakStore5

The software Peakalyzer Manager serves as interface to manage the data collection systems PeakStore504, PeakStore508 and PeakStore512. At first the license of the according PeakStore5 must be added to the Peakalyzer Manager. The license manager is available via the menu item Extras → Licenses. Via the button Add License the license that is delivered with the PeakStore5 can be added. The coupling of the PeakStore5 to the tablet is done via the expansion port in the standard delivery. This expansion port is activated automatically during the boot process of the tablet but can also be activated manually via the tablet module configuration.

If the PeakStore5 is used via the separate USB connection in combination with a normal PC, the USB connection must be first established before the PeakStore5 is added to the Peakalyzer Manager. Afterwards the PeakStore5 can be added to the Peakalyzer Manager via the menu item Diagnosis system → New → PeakStore. The button Search lists all supported measurement devices that are connected via USB.


The PeakStore5 is then listed in the device browser of the Peakalyzer Manager like any other system. After the selection of the PeakStore5 in the device browser, a query of the channel properties is done and the configuration site is opened.

Via the menu Extras → Options → PeakStore → General the directory where all measurement data should be saved can be chosen. Additionally, a shortcut to the desktop or in the Windows startup can be created. This will start the Peakalyzer Manager and automatically select the desired PeakStore5 and will start the settling process with the active configuration.

6.1 Configuration

In the configuration view, there is a menu bar in the bottom with some general functionalities. The button New will create a new configuration. The button Activate will choose the currently opened configuration as measurement configuration. This active configuration will also be automatically loaded if the PeakStore5 is selected in the device browser. The button Save will save all changes of the currently opened configuration if there are no validation errors. If invalid configuration parameters are set, a window will be opened with description of the invalid parameter. The button delete will delete the selected configuration. This is only possible if there are no measurement data existent for this configuration. If applicable, these have to be deleted in the [data management](#) first.

6.1.1 General



The menu tab General of the selected configuration contains the following parameters:


- **Name of Configuration:** An arbitrary alphanumeric name to identify the configuration. This name is also inserted in the measurement protocol.
- **Configuration Type:** It can be chosen between vibration measurement and balancing in one or two layer. Details for the balancing can be found in chapter [balancing](#).
- **Online-Calculation of Spectra:** This option can be activated if the online calculation of online order and frequency spectra is desired during the measurement. If the online calculation is not activated the battery life time is increased.
- **Show IP Address for App:** If this option is activated, the IP Address of the WLAN adapter of the tablet is shown in the sensor overview.

Additionally, the following information are available on the general site:

- The number of available speed and sensor channels
- The number of configured speed and sensor channels
- The date of the calibration data. Also, a new calibration file can be loaded in this section.

The amount of available measurements with the current channel settings. If the measurement time is set to undefined on the vibration channel site, the maximum storage time is shown.

6.1.2 Speed Channels



On the site Speed Channels the speed sensors can be configured. In general, there are two input channels for speed sensors available. Via the button Speed Channels → New a new speed sensor can be added. In the table an arbitrary name can be set for this channel. Additionally, the impulses per rotation that are measured by the sensor must be adjusted to the correct value. The trigger threshold of the speed channel can be adopted if necessary. The speed sensors that are delivered by GfM Gesellschaft für Maschinendiagnose mbH work ideal with the standard value of 5 V.

If no speed sensor is configured, the online calculation of spectra is reduced to frequency and envelope frequency spectra. The calculation of order and envelope order spectra requires a speed measurement. For the configuration type balancing it is required to measure the speed.

6.1.3 Vibration Channels

Name	Channel	Reference speed	Sensitivity / V	Offset	Unit	Measurement range	Measurement...	Sampling frequen
Sensor1	Analog 1	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200
Sensor2	Analog 2	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200
Sensor3	Analog 3	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200
Sensor4	Analog 4	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200
Sensor5	Analog 5	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200
Sensor6	Analog 6	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200
Sensor7	Analog 7	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200
Sensor8	Analog 8	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200
Sensor9	Analog 9	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200
Sensor10	Analog 10	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200
Sensor11	Analog 11	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200
Sensor12	Analog 12	Drehzahl1	100	0	m/s ²	-1,000.00 m/s ² to 1,000.00 m/s ²	163.84	51200

On the configuration site Vibration Channels, the individual analogue inputs can be configured. Via the button Vibration Channels → New a new sensor can be added and afterwards be configured in the table. The following parameters are available:

- **Name:** an arbitrary name for the sensor description or name of the measurement position.
- **Channel:** the corresponding input channel
- **Reference Speed:** the speed that is used for the order spectra of this sensor
- **Sensitivity / V:** the sensitivity of the sensor. If a calibration file is given on the general site, the value from the calibration file is used automatically.
- **Offset:** the offset of the sensor. For accelerometers with IEPE interface this value is usually 0. For analogues displacement sensors, the offset of the displacement sensor must be entered.
- **Unit:** the physical unit of the sensor
- **Measurement range:** the measurement range of the channel. Here you can select from ± 10 V to ± 1 V.
- **Measurement time:** the measurement time is changed for all channels accordingly. It can be chosen from a pool of 8 measurement times. Alternatively the measurement time can be set to undefined. In this case the measurement must be stopped explicitly to finish the measurement.
- **Sampling frequency:** The sampling frequency can be set individually for each channel from a pool of 9 sampling frequencies.
- **Coupling:** The coupling can be chosen for each channel individually from IEPE, AC or DC.

If the configuration type balancing was chosen, a balancing layer must be assigned to each sensor. Furthermore, the sampling frequency is fixed to 51.2 kHz for all sensors.

6.1.4 Characteristic Values


Name	Characteristic value	Unit	Warn threshold	Alarm threshold
Sensor1	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s
Sensor2	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s
Sensor3	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s
Sensor4	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s
Sensor5	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s
Sensor6	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s
Sensor7	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s
Sensor8	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s
Sensor9	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s
Sensor10	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s
Sensor11	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s
Sensor12	DIN ISO 10816-3	Vibration velocity	1 mm/s	2 mm/s

For accelerometers that are configured in the vibration channels site, a characteristic value can be configured on this site. If an accelerometer is added, the r.m.s. of vibration velocity based on DIN-ISO 10816-3 is preconfigured for this sensor. The following r.m.s. values of vibration velocity or vibration acceleration can be configured for each sensor:

- DIN-ISO 10816-3 with bandwidth 10 Hz – 1 kHz
- DIN ISO 10816-21 with bandwidth 0.1 Hz – 10 Hz
- DIN ISO 10816-21 with bandwidth 10 Hz – 1 kHz
- DIN ISO 10816-21 with bandwidth 10 Hz – 2 kHz
- DIN ISO 10816-21 with bandwidth 10 Hz – 5 kHz

For each characteristic value a warning and an alarm threshold can be configured. It is then possible to monitor warn and alarm threshold exceeding in the measurement overview.

6.1.5 Protocol Template



A measurement protocol template can be chosen from a pool of templates. The templates of type *(Drawing)* contains a drawing surface where a schema of the machine can be drawn by hand. The data type *(Picture)* contains a preset machine schema picture. Templates with the data type *(Empty)* omits the sensor overview completely. The following templates are available:

- 2 Spur gear stage + Planetary stage
- 3 Spur gear stage
- 4 Spur gear stage + Planetary stage
- A60-B130
- Blade bearing
- Motor
- Planetary stage + 2 Spur gear stage
- Motor
- Motor + Gear box
- Turbine + Gear box + Generator
- Empty Template

Additionally, the sensor positions can be placed beforehand if the selected protocol is of the type *(Picture)*. These are then used in each measurement with this configuration. At first the check "Activate automatic sensor placement" must be set. The desired position has to be clicked to place the sensor. If an already placed sensor is clicked again, a popup will open to change the measurement position and direction.

6.2 Vibration Measurement

If the PeakStore5 is selected in the device browser, the measurement overview of the active configuration is automatically selected. The configured channels will be activated and the settling process of the input channels will start. The settling process can also be cancelled. The PeakStore5 is then deactivated and must be activated via the button "Activate PeakStore" before a measurement starts. If the PeakStore5 is active, the PeakStore5 can be deactivated via the same button or the function key Fn2 on the top of the

PeakStore5. If activated, the PeakStore5 is in a monitoring mode where the current characteristic values and the current speed can be viewed.

This also increases the power consumption of the PeakStore5. If the monitoring mode is not needed, it is recommended to deactivate the PeakStore5 to increase the battery life time.

A measurement can be started by pressing the Start button in the right bottom of the application.

Alternatively the function key Fn1 on the front bottom of the tablet can be used to start a measurement. If the PeakStore5 is deactivated, the settling process will start first before the actual measurement is started automatically.

If a predefined measurement time is configured and the measurement is cancelled via the stop button during the measurement time, all measurement data of the current measurement will be withdrawn.

To switch between the different measurement views, the navigation buttons in the right top of the application can be used. The Home button always leads to the [sensor overview](#).

6.2.1 Sensor Overview




The sensor overview site is the main site of the measurement overview. Above the actual sensor information are buttons to open the current configuration and to open the data management as well as the activation/deactivation of the PeakStore5. Additionally, there are information of the current measurement start time and the current measurement number. Also the available free measurements that depend on the free disk space is shown.

For the individual sensors the following information are displayed:

- *Accelerometers*: The current characteristic value that is configured for this sensor.
- *Displacement sensors and other sensors*: The current measurement value is shown.
- *Speed*: The current speed value. Additionally, the variation of the speed in percent during the measurement.

By pressing on the sensor, the time signal of the selected sensor will be shown.

6.2.2 Measurement Protocol



All relevant additional information that are important for the measurement can be added in the measurement protocol. Depending on the chosen measurement protocol template in the configuration, the provided data can vary. Some information will be filled automatically, like the configuration name, the current measurement number and the date of measurement.

The measurement protocol is divided in the following categories:

General

- Name and company of the measurer
- Measurement start time will be filled automatically

Machine information

- Manufacturer, type, number, location, nominal power and operator of the machine
- Manufacturer, type, number, nominal speed and ratio of the gear box if present
- Manufacturer, type, number and bearing description of the motor or generator

Speed measurement

- Positioning of the speed sensor
- Impulse per revolution is taken from the configuration

Measurement

- Current measurement number will be filled automatically
- Configuration name will be filled automatically
- Order number if available
- Process information, e.g. current wind speed or actual power output

Sensor overview


The measurement protocol templates of type (*Picture*) have a preset picture. The measurement positions of the individual sensors can be placed on this picture. The desired position has to be clicked to place the sensor. If an already placed sensor is clicked again, a popup will open to change the measurement position and direction.

If the same sensor arrangement is used in multiple measurements, it is recommended to save the positioning. This can be done by pressing the save button above the picture. The position will be saved under the given name. By pressing the load button the selected positioning is applied to the current picture. If a measurement protocol template of data type (*Drawing*) is chosen, a schema picture of the machine can be drawn by hand. The drawing mode can be activated by pressing the Design button in the sensor overview. The empty box can be used to draw any picture. The completed picture can be saved as separate picture file or copied to the clipboard to use it in another application. Additionally, there are functionalities to revert the last operation, erase parts of the picture or delete the complete picture.

Miscellaneous


- An arbitrary text that can contain additional information of the measurement

6.2.3 Time Signals




On this site the measured time signals of all sensors, also in parallel, can be viewed. The signals that should be shown, can be changed by the sensor listing on the right side. The curve window is frequently updated to show the latest data during the measurement. If the measurement is finished, the curve window can be zoomed freely to show certain parts in detail.

6.2.4 Spectra



If the online calculation of spectra is activated in the configuration, the order, envelope order, frequency and envelope frequency spectra of up to four sensors can be displayed. The spectrum type can be chosen by the buttons above the curve window. The spectra are recalculated multiple times during the measurement with increasing resolution. Thus the spectra with the best resolution are available at the end of the measurement. If an undefined measurement time is chosen, the resolution of the calculated spectra will increase up to 163,84 s. From this point on the last 163,84 s are used in a ring buffer system to calculate a new spectrum.

6.2.5 Characteristic Values



Warning and alarm thresholds can be configured for each characteristic value of the accelerometers. The visualization of the characteristic values can be found on the characteristic value site. The characteristic value is recalculated continuously during the measurement for each sensor. The graphical view displays the minimal and maximal value during a measurement with a horizontal line. The current characteristic value is visualized with a small arrow. The configured warning and alarm thresholds are emphasized with green, yellow and red ranges. If the mouse is hold over a sensor, the concrete values are shown in a popup window.

For connected displacement sensors, speed sensors or other sensors the minimal, maximal and current value of the physical measured unit are shown.

The upper bound of the y-axis is adjusted simultaneously for all characteristic values of the same type. This allows an easier comparison of the characteristic values. This behavior can be changed in the options under Extras → Options → PeakStore → Characteristic Values. Furthermore the coloring of the sensor name can be changed to show different characteristic value types in different colors.


6.3 Balancing

If a configuration of type balancing is selected, the measurement view for the balancing process is shown. The usual sensor overview from the vibration measurement is replaced by an assistant driven overview for the balancing process. The pages for time signals (see [Time Signals](#)), online spectra (see [Spectra](#)) and characteristic values (see [Characteristic Values](#)) are identical to the vibration measurement.

The balancing process is done in multiple stages. At first an origin measurement is done to determine the initial imbalance of the machine. Afterwards a test measurement with a test mass is required to calibrate the system. If the balancing is configured for two layers, a second test measurement on the second layer is required. Afterwards up to 5 validation measurements will follow where balancing masses are applied to the layers to reduce the initial imbalance.

Generally, each measurement consists of a preparation phase, the actual measurement and an acknowledgment of the current measurement. If a misconfiguration was done, the current step can be cancelled at any time to go back to the last step. During the measurement phase, the PeakStore will wait until the speed is in a valid range and then start the actual measurement. If the speed changes during the measurement to an invalid range, the measurement is stopped immediately. The speed must be in the valid range to automatically restart the measurement.


The main results of the balancing process are aggregated in a polar view and can be shown at any time of the measurement.



A protocol of the whole balancing process is shown and saved after the balancing process is finished.

6.3.1 Preparation

Before the actual balancing process can be started, the vibration sensors and the speed sensor must be applied. A reflection mark must be placed ideally on one of the balancing layers for the speed measurement. This mark is also the 0° reference position for the later process that is relevant for applying masses. The speed sensor must be placed with the holder that it shows directly on the reflection mark. Additionally, the vibration sensors must be placed directly on the bearing of the balancing layer. Ideally it is placed directly on the housing of the bearing. The type of the vibration sensor must be chosen that the lower cut off frequency is below the speed frequency. If configuration type is set to balancing in one layer, the vibration sensor must be placed on this layer. If balancing in two layers is activated, one vibration sensor must be placed on each layer. It is necessary to take into account the correct layer for each vibration sensor, as parametrized in the configuration (see also [Vibration Channels](#)).



Afterwards, the following parameter must be set for the whole balancing process (see also above Picture):

- **Target speed:** This speed is used for the whole balancing process. Ideally the balancing process is done at normal operational speed of the machine. It should be avoided to balance the machine in the resonance range.
- **Speed tolerance:** The acceptable deviation from the given target speed. A maximum tolerance of 50% is allowed.
- **Number of revolutions:** One measurement in the balancing process is done with the given number of revolutions. It will be automatically rounded to the nearest power of two. The expected measurement time directly results from the combination of the number of revolutions and the target speed.
- **Balancing target:** The imbalance of the machine can be determined via the measured vibration acceleration or via the inferred vibration velocity.
- **Count direction:** It can be chosen between clockwise and counterclockwise. The reflection mark always references the position 0°. The count direction on the balancing layer is always from the perspective of the speed sensor, thus with view on the reflection mark.
- **Use fixed positions:** If masses can only be applied to dedicated positions, this option must be checked. The positions must be distributed equidistantly over the whole balancing layer.
- **Number of fixed positions:** The number of fixed positions must be entered here, if the option “use fixed positions” is activated.
- **Rotor mass:** The mass of the rotor in gram. The information is required to calculate the quality level after the balancing according to DIN ISO 21940-11:2017-03.
- **Radius of mass positions:** For the calculation of the quality level according to DIN ISO 21940-11:2017-03 the radius of mass positions is also required. It is the distance of the mass position to the centre of the balancing layer. On these positions the test masses as well as the balancing masses must be applied.

6.3.2 Origin Measurement

The origin measurement can be started by clicking on continue, if all parameters are set up. It will be first waited until the speed is in the valid range. If this is the case the actual measurement starts automatically and also stops automatically if the required number of revolutions are reached.

6.3.3 Test Measurement

A calibration of the system is required to calculate the correct balancing masses. For a balancing in one layer, a test measurement with a test mass on this layer is required. If the balancing is done in two layers, an additional test measurement with a test mass on the second layer must be done. The test masses must be removed from the corresponding layer after each test measurement. The example in below Picture shows an application of a test mass of 80 g at position 60°. After the machine is at the expected target speed, the measurement can be started. If the balancing is done in two layers, the mass can be removed from the first layer and applied to the second layer.

▼ 1st test measurement Layer 1

Position test mass: °

Weight of test mass: g

6.3.4 Validation Measurement

The balancing masses to correct the initial imbalance are calculated after the successful test measurement. If the option “use fixed positions” was activated, two masses per layer are calculated. The picture below shows an exemplary calculation of required balancing masses to reduce the initial imbalance. If it is not possible to apply the exact masses to the locations, the actually applied masses can be entered.

▼ validation measurement 1

Target values:

Layer 1	Degree: 300,00°	Weight: 499,378 g
Layer 1	Degree: 360,00°	Weight: 241,412 g

Actual values:


Layer 1	Degree: <input type="text" value="300,00"/> °	Weight: <input type="text" value="499,378"/>
Layer 1	Degree: <input type="text" value="360,00"/> °	Weight: <input type="text" value="241,412"/>

Quality level:


After the masses are applied, a validation measurement is required. The determined quality level will be shown in the window afterwards. If the required quality level was not reached, a further validation measurement can be added to the balancing process. The additionally calculated masses must be added to the existing masses from the last validation measurement. This step can be repeated up to 5 times.

6.3.5 Finalization

If the target quality level is within the desired range, the balancing process can be finished after the validation measurement. The protocol of the balancing process will directly be shown in an internal pdf viewer. The measurement data and protocol are also available in the data management section afterwards.




6.4 Data Management



The data management handles all recorded measurement data of the PeakStore5. All measurement data are structured in the left tree view. The button View above the measurement listing allows to change the structuring of the measurement data listing. The following options are available:

- **Machine View:** The measurement data is grouped according to the measured machine.
- **Configuration View:** The measurement data is grouped according to the used configuration.

- **Order View:** The measurement data is grouped according to the order number that was entered in the measurement protocol.
- **Chronology View:** The measurement data is listed chronologically without any further grouping. If one measurement is selected, the measurement data can be visualized by pressing the button “Show measurement”. On the right side, the desired sensors can be chosen. By default the speed signal is preselected if one measurement is shown. If there are additionally photos saved, that were recorded with the [PeakStore Remote App](#), these can be displayed by pressing the button “Show photos”.



The generated measurement protocol can be viewed in an integrated pdf viewer if the button „Show report” is pressed. From this view the pdf can also be saved in a separate file or be outputted to a connected printer.

If the measurement protocol contains erroneous inputs, the entered data can be changed by pressing the button “Change report”. This will open the edit mode of the measurement protocol as described in the measurement overview. To save the changes, the button “Save report” has to be pressed.

If measurements or complete machines in the left data browser are selected with a check, these data can be exported, deleted or calculated with the Diagnostic Tool. For the data export a separate window will open where the desired target directory can be chosen. Thus a connected USB-Stick can be chosen to export the data. The selected measurement data will be compressed to a single file for all measurements or a single file per measurement. The measurement data will be exported to the GfM internal raw data format by default. Alternatively, the data can be exported to WAV or ASCII format.

If desired, the measurement data can be deleted after the export finishes.

Additionally the measurement data can be transmitted to a FTP server. For example the data can be transferred to GfM Gesellschaft für Maschinendiagnose mbH directly after the measurement for an analysis. Alternatively the measurement data can be uploaded to any other FTP server. A stable internet connection, e.g. via WLAN, must be available to use the FTP upload functionality. Also the FTP login data must be known.

Export

Storage path: D:\Backup\ Search

Data format: GfM Format

Pack all measurement data in one file

Delete measurement data after export

Activate FTP Upload

Server name: ftp.strato.de

User name: temp3@maschinendiagnose.de

Password: ●●●●●●●●


OK Cancel

Via the button „Delete“ all selected measurement data will be completely deleted from the PeakStore5 after an additional question.

The selected measurement data can be calculated with the Diagnostic Tool if the button “Calculate” is pressed. The Diagnostic Tool will open and the checked data will be preselected for further editing and calculation.


6.5 Remote Control

There is a free of charge App for the Smartphone platforms Android from version 4.1 and iOS from version 9.2 available that allows the remote control of the PeakStore5. The PeakStore Remote App must be installed from the corresponding Store. An active WLAN connection must be established between Smartphone and PeakStore5 to get the PeakStore Remote App working. It is recommended to use an additional WLAN route as access point between these two where both devices are connected to. A battery driven WLAN router can also be ordered as additional component at GfM Gesellschaft für Maschinendiagnose mbH.



If the WLAN connection is established on both sides, the PeakStore Remote App can be started and a broadcast search for the PeakStore5 can be done. If the PeakStore5 is not automatically found, the PeakStore5 can be added manually. Therefore the IP address of the WLAN connection of the tablet, that is shown in the sensor overview if configured, must be entered in the App.

If the connection to the PeakStore5 is established successfully, the overview page will open. The PeakStore5 must be in the measurement overview. If the configuration view or data management is opened, a measurement can not be started.



In the upper part of the App common information of the measurement are displayed. These are:

- The name of the configuration
- The measurement progress in percent
- The current measurement time
- The current measurement number

The measurement progress is also visualized with the progress bar.

Furthermore there is an overview of all sensors with their current, minimal and maximal characteristic values of accelerometers or speed values of speed sensors displayed. The minimal and maximal values are only updated during a measurement. If the measurement is currently stopped, only the current value is updated.

Via the button Start on the right bottom a measurement can be started. If a configuration with an undefined measurement time is activated, the measurement can also be stopped with the same button.

Additionally photos can be taken and saved in the measurement with the PeakStore Remote App. These can be photos of type designations, photos of the machine or sensor positioning. The taken photos are directly transmitted to the PeakStore5 and are saved in the current measurement after confirmation. An arbitrary free description and a category (machine picture, generator picture, gear box picture or other) can be added for each picture.

7 Diagnostic Tool


The Diagnostic Tool provides the functionality to calculate measurement data of PeakStore5 and other measurement systems. According to the configuration frequency and envelope spectra as well as order and envelope order spectra are calculated. Additionally the characteristic values r.m.s. of vibration velocity and vibration acceleration are calculated for each accelerometer. Furthermore the kinematic of the complete machine can be entered in the fully licensed version. Found irregularities on the configured drive elements are then reported. A future version will also contain a full report generator to create a complete diagnosis report in the Peakalyzer Manager.

The fully licensed Diagnostic Tool can read the following data formats besides the PeakStore5 data:

- PeakStore200, PeakStore400, PeakStore410
- DasyLab
- Famos
- Diadem
- Universal File Format
- Bachmann

The Diagnostic Tool can be opened via the menu point Diagnosis System → Diagnostic Tool if at least one license is added in the license manager.

7.1 Licensing



Via the menu point Extras → License an overview of all added licenses is shown. Licenses of the following types can be added:

- PeakStore5 (Diagnostic Tool Standard)
- Diagnostic Tool Professional
- Diagnostic Tool Ultimate

The Diagnostic Tool Standard license can be added to any number of computers. The license allows the calculation of measurement data that are from the PeakStore5 with the specific serial number. If only

PeakStore5 licenses are added to the license manager, all other data formats are not recognized. The license of the PeakStore5 has only a reduced functionality. All kinds of spectra and characteristic values can be calculated, but the search for kinematic patterns and the report generator is not available. The Diagnostic Tool Professional and Ultimate license is bound to a specific computer and can not be transferred to another computer. The Diagnostic Tool Standard license supports all available data formats. With the Diagnostic Tool Ultimate license all data can be also analyzed with an advanced analysis.

7.2 Measurement Selection

Via the button Browse a measurement directory can be chosen in the Diagnostic Tool. Afterwards the selected directory can scanned recursively for measurement data via the button Scan. After the scan is finished, all measurement data that are supported by the Peakalyzer Manager are shown in the left data browser. The listed measurement data can be grouped by the following categories:

- **Raw data:** the measurement data are listed according to their directory structure
- **Machine:** the measurement data are grouped by the measured machine
- **Order:** the measurement data are grouped by the entered order number

The order number and machine name can be individually adjusted for each measurement. Accordingly the corresponding data browser view is adjusted.

It is possible to exclude single measurements from the calculation. This can be done by opening the context menu of the entry by right clicking and clicking delete. For each measurement, the read raw signals can be viewed by selecting the desired measurement. The speed signal is shown by default if available.

Via the selection box raw signal in the right bottom any other time signal can be displayed.

Above the curve window all process information like speed, wind or power that are saved in the measurement are shown. These can also be edited and extended individually for each measurement.

These process factors can be used later for filtering the shown data in the analysis.

Additionally the following general information are shown:

- Data format of the measurement
- Name of the measurement device
- Measurement date
- Measurement number
- Machine name
- Order number

- Output directory

In the output directory, a subdirectory with the measurement date will be created to save all the calculated results. This directory can also be a network drive. Especially if multiple computer in the network uses the Diagnostic Tool with the same database it is strongly advised to use an output directory that is available on all computer. Otherwise the calculated data can not be opened on the other computer. Additionally the output directory will contain the original raw data. Thus the input directory can be on a local drive and only the output directory on a network drive. The output directory should not be moved or deleted manually. Otherwise the Peakalyzer Manager can not access the data anymore.

Before the actual calculation is done, each measurement can be configured with an individual [preprocessing](#). Further information are described in the next chapter. Via the button "Calculate All Data" in the left bottom, all measurement data that are shown in the data browser are calculated. Afterwards the calculated machines are added to the device browser in the Peakalyzer Manager. These can then be displayed and analyzed as described in [Analysis](#).


7.3 Preprocessing

Each measurement that is listed in the data browser can be configured with an individual preprocessing. The processed signals can be viewed via the selection in the right bottom. Especially for the speed processing it is advised to check whether the result meets the expectation. The following preprocessing options are available:

Fixed Speed


If no speed was measured and the machine was driven with a fixed speed, the speed value can be directly entered. This option can be applied to all other measurements in the data browser.

Speed from impulse signal



If the signal of the speed sensor was measured analogues, the square pulse signal can be converted into a speed signal. The correct time signal must be chosen and the trigger threshold must be adjusted. The threshold can be entered manually. Alternatively the time signal can be display via the show button. The trigger threshold can be then dragged in the curve window. The result should be verified afterwards.

Speed from meshing



With this function the speed signal can be determined by the meshing frequency of a gear box. From the selected sensor signal short-FFTs are calculated and displayed as spectrogram. A frequency range of a significant frequency, for example the meshing frequency, can then be selected in the displayed curve window. The range can be selected by dragging the gray area on the desired frequency. Alternatively the frequency start and end point can be entered manually. Additionally a factor can be entered that corresponds to the multiple of the actual speed value.

Impulse correction

If the measurement was done with the wrong number of impulses per revolution, this factor can be corrected with this function. This option can be applied to all other measurements in the data browser.

Eliminate outlier in speed signal

If the speed signal contains spikes or outlier, these can be eliminated. The detected part is replaced with a linear interpolation of the start and end value of the replacement. This option can be applied to all other measurements in the data browser.

Smooth speed signal

The speed signal can be smoothed over the entered time period to eliminate noise. This option can be applied to all other measurements in the data browser.

Cut signals

If the measurement contains unwanted effects like a run-up of the machine, the signals can be cut to leave out the undesired part. An arbitrary sensor can be chosen to select the desired range by displaying the sensor signal and drag the gray area accordingly. During the calculation, all sensor signals are cut to the same length.

Change unit

If the measurement device was configured with the wrong unit or sensitivity, these parameters can be corrected with this function. The unit and sensitivity can be adjusted for each sensor separately. This option can be applied to all other measurements in the data browser.

Change sampling frequency

If the raw data contains the wrong sampling frequency, this value can be corrected. This will only change the sampling time between two data points. There will be no interpolation of the data with the new sampling frequency. This option can be applied to all other measurements in the data browser.

Envelope


The high-pass filter for the envelope calculation can be adjusted. Especially for large structures with slow speed it may be wise to set a smaller frequency for the envelope calculation. For the most applications the default value of 2 kHz is sufficient. This option can be applied to all other measurements in the data browser.

FFT Parameter

The length of the resulting spectra can be adjusted with this setting. This is only an approximate value. The actual value will be determined during the calculation by rounding to the next FFT size. This option can be applied to all other measurements in the data browser.

Sensor assignment

The labeling of the sensor can be changed for example to adjust the name to the actual measurement position. The sensor signals are listed under the new name in the analysis. A complete sensor assignment can also be saved as a scheme. This scheme can then be applied to other measurements. The scheme is only applied to sensors with the same origin name. The saved schemes for the sensor assignment can be edited via the menu point Templates → Diagnostic Tool → Sensor Assignment.



The individual assignment of sensor names can be edited for each scheme. Thus it is possible to have the same target sensor name for multiple source sensor names to for example support nomenclatures of different measurement devices in one scheme.

7.4 Base Diagnosis

All machines and corresponding measurements that are calculated can be configured with individual characteristic values. To configure these characteristic values the machine has to be selected in the left data browser. Alternatively the machine can be selected by clicking on the button next to the machine name on the general information tab of an active measurement.

The screenshot shows the 'Diagnostic Tool' interface. On the left, a tree view shows the selected machine '701290' and two measurement points. The main area displays the 'Characteristic values' tab for machine '701290'. The table below lists various sensors and their corresponding characteristic values, including low pass filter, high pass filter, averaging time, generation frequency, warn threshold, and alarm threshold.

Sensor	Characteristic value	Low pass filter	High pass filter env	Averaging time	Generation freque...	Warn threshold	Alarm threshold
Sensor12	DIN ISO 10816-3 Vibration velocity					2 mm/s	5 mm/s
Sensor12	DIN ISO 10816-3 Vibration acceleration					4 m/s ²	8 m/s ²
GA	DIN ISO 10816-3 Vibration velocity					2 mm/s	5 mm/s
GA	DIN ISO 10816-3 Vibration acceleration					4 m/s ²	8 m/s ²
GB	DIN ISO 10816-3 Vibration velocity					2 mm/s	5 mm/s
GB	DIN ISO 10816-3 Vibration acceleration					4 m/s ²	8 m/s ²
ZWG	DIN ISO 10816-3 Vibration velocity					2 mm/s	5 mm/s
ZWG	DIN ISO 10816-3 Vibration acceleration					4 m/s ²	8 m/s ²
ZWR	DIN ISO 10816-3 Vibration velocity					2 mm/s	5 mm/s
ZWR	DIN ISO 10816-3 Vibration acceleration					4 m/s ²	8 m/s ²
SWG	DIN ISO 10816-3 Vibration velocity					2 mm/s	5 mm/s
SWG	DIN ISO 10816-3 Vibration acceleration					4 m/s ²	8 m/s ²
SWR	DIN ISO 10816-3 Vibration velocity					2 mm/s	5 mm/s
SWR	DIN ISO 10816-3 Vibration acceleration					4 m/s ²	8 m/s ²
HR	DIN ISO 10816-3 Vibration velocity					2 mm/s	5 mm/s
HR	DIN ISO 10816-3 Vibration acceleration					4 m/s ²	8 m/s ²
HG	DIN ISO 10816-3 Vibration velocity					2 mm/s	5 mm/s
HG	DIN ISO 10816-3 Vibration acceleration					4 m/s ²	8 m/s ²
MA	DIN ISO 10816-3 Vibration velocity					2 mm/s	5 mm/s
MA	DIN ISO 10816-3 Vibration acceleration					4 m/s ²	8 m/s ²
MA	DIN ISO 10816-21 10 Hz - 5 kHz Vibration velocity					0 mm/s	0 mm/s
MB	DIN ISO 10816-3 Vibration velocity					2 mm/s	5 mm/s
MB	DIN ISO 10816-3 Vibration acceleration					4 m/s ²	8 m/s ²
MB	DIN ISO 10816-21 10 Hz - 5 kHz Vibration velocity					0 mm/s	0 mm/s

Each sensor can be configured with one or multiple characteristic values with each individual warn and alarm thresholds.

Important: If the sensor assignment of one measurement is changed, the characteristic values are reset to its default values. Thus it is practicable to first set the sensor assignment of the measurements correctly and then configure the characteristic values as desired.

To facilitate the configuration of the characteristic values, it is possible to create templates for all or specific sensor names.


Sensor	Characteristic value	Low pass...	High pass...	Averaging time	Generation freque...	Warn threshold	Alarm threshold
[General]	DIN ISO 10816-3 Vibration velocity			-	-	0.1 mm/s	0.5 mm/s
[General]	DIN ISO 10816-3 Vibration acceleration			-	-	4 m/s ²	8 m/s ²
MB	DIN ISO 10816-21 10 Hz - 5 kHz Vibration velocity			-	-	0 mm/s	0 mm/s
MA	DIN ISO 10816-21 10 Hz - 5 kHz Vibration velocity			-	-	0 mm/s	0 mm/s

Templates of characteristic values can be edited via the menu point Templates → Diagnostic Tool → Characteristic Values. Multiple different characteristic values can be created for each sensor name. Additionally templates that are used for all sensors can be created. These have to use the sensor name "[General]". After the characteristic values are saved, they are available upon the next configuration of a Diagnostic Tool setup.

If the warn and alarm thresholds are configured, the corresponding warn and alarm bands are shown in the subsequent [data analysis](#). An alarm threshold exceeding is also shown in the machine overview as [characteristic value alarm](#) of the corresponding machine afterwards. Via this alarm the data in the analysis can also be shown up.

7.5 Advanced Diagnosis

With a [license](#) of the Diagnostic Tool Ultimate it is possible to enter a kinematic for a machine. If a certain machine is measured and calculated several times, it is useful to enter the kinematic of the machine as [template](#) to reuse this template on subsequent calculations. By this procedure it is also ensured that the calculated data of drive elements are shown in connection to the previous data in the analysis.



The machine template can be directly chosen and loaded in the overview of drive elements. Afterwards only the assignments of drive elements to the sensors must be set. The kinematic can be extended by further drive elements or be build up completely by adding drive elements. The whole configuration of the gear is described in detailed in the section [drive elements](#).

Important: If the sensor assignment of one measurement is changed, the drive element assignments are reset to its default values. Thus it is practicable to first set the sensor assignment of the measurements correctly and then configure the kinematic as desired.

After the calculation, the found irregularities are listed as [alarms of vibration diagnosis](#) in the machine overview of the corresponding machine. From this view it is also possible to directly show the spectrum with marked diagnosis attributes to verify the found irregularities.

7.6 Calculation

Via the button "Calculate All Data" on the left bottom, the following data are calculated for all measurements in the data browser:

- frequency and envelope spectra
- order and envelope order spectra if a valid speed signal exists
- r.m.s. of vibration velocity and vibration acceleration for all vibration signals

The resulting data are saved under the configured machine. After the calculation the machine is added to the device browser in the Peakalyzer Manager and can be viewed in the analysis. If the same measurement is calculated again, the old result will be withdrawn and replaced with the new one. A message will be displayed on the corresponding measurement in the data browser.

The resulting machine and its data can be additionally saved for backup purposes via the menu Diagnosis System → Export.

8 Machine Overview

The state of the machine can be observed on multiple layers. If an hierarchical layer is selected in the device browser, all machines that are in this layer or subsequent layers are shown. Thus a short overview over multiple machines distributed over multiple plants or locations is possible.

The screenshot shows the Peakalyzer Manager interface. On the left is a hierarchical tree structure under 'Ebene 1' and 'Ebene 2'. The main area displays a table of machines with columns for 'Machine', 'Alarms', 'Alarms in time frame', 'Peakalyzer State', 'Comments', and 'Comments in time frame'. The time frame is set from 5/23/2019 to 8/21/2019, and the filter is 'Peakalyzer/Diagnostic Tool'. The machine 'Anlage1' is selected, showing details for IP 10.10.161.22, including current alarms, alarms in the time frame, peakalyzer state, and user comments.

Machine	Alarms	Alarms in time frame	Peakalyzer State	Comments	Comments in time frame
Anlage1	5	24	1	1	1
Anlage2	2	0	1	1	1
Anlage2-PB-Check	0	0	1	1	1
Blockheizkraftwerk	0	187	0	1	1
Firmware_Test2	13	130	1	0	0
Klassierung_Test	3	22	1	0	0

In this view the number of alarms that are currently present on this machine are shown. Additionally a time frame can be set to view the number of alarms that occurred in the given time frame. Each machine can be unfolded to show further details of the machine, for example the number of alarms separated by the type. The machines can be filtered by several criteria. Thus it is possible to show only all Peakalyzer or their corresponding machines that have connection problems. For each individual machine the user defined comments as well as the number of user defined comments in the filtered time frame are shown. Via the button add user comment in the top next to the name of the hierarchical layer, a user comment can be added to the Peakalyzer or machines in this layer. This function is also available if the machine view of one individual machine is displayed.

The screenshot shows a dialog box titled "New Comment - All groups". It contains the following fields and options:

- Text:** A text input field containing "Test sensors".
- Priority:** Three radio buttons: "Kommentar" (unselected), "Monitor" (selected), and "Urgent" (unselected).
- Author:** A text input field containing "SPlath".
- Shown until:** A checked checkbox followed by a date field showing "8/28/2019".
- Create for:** Two checked checkboxes: "Peakalyzer" and "Machines".

At the bottom of the dialog are "OK" and "Cancel" buttons.

A priority can be chosen, when a new user comment is added. The user comments with higher priority are also indicated in the device browser. A user comment with priority urgent will result in a red color for the machine, a monitor priority colors the machine yellow and a normal comment will not change the color of the machine. Additionally an expiration can be entered for the comment. The comment is then only shown until this date in the machine overview. Nevertheless it is available in the [logbook](#) afterwards. The comment can be added for a Peakalyzer as well as for the machine that are in this layer.

By selecting the machine in the device browser or via the arrow next to the machine name in the group overview, the detailed machine view is displayed. This view shows individual information for each alarm. If an alarm is present in a certain category, the corresponding box is expanded and the machine is colored red in the left tree view. The following detailed views are visible for one machine:

- [General Information](#)
- [Sensor Overview](#)
- [Alarms Vibration Diagnosis](#)
- [Alarms Characteristic Values](#)
- [Alarms Process Factors](#)

8.1 General Information

The screenshot displays the Peakalyzer Manager software interface. The main window is titled 'Planetengetriebe mit Stirradstufe' and shows the following information:

- Machine Details:**
 - Name: Planetengetriebe mit Stirradstufe
 - Manufacturer: Demo
 - Type: D0
 - Location: Berlin
 - Nominal Power: 500 kW
 - Operator: Demo
- Gearbox Details:**
 - Name: D1
 - Manufacturer: Demo1
 - Type: D9
 - Nominal Speed N1: 1800 1/min
 - Nominal Speed N2: 60 1/min
 - Ratio: 30
- Generator/Motor Details:**
 - Name: D5
 - Manufacturer: Demo3
 - Type: D5
 - Bearing DE: 6330
 - Bearing NDE: 6330
 - Note: This generator is electrically coupled
- User Comments:**


Created on	Shown until	Author	Text
05.08.2019	12.08.2019	Reinke	Motorlager prüfen
- Diagram:** A schematic diagram of the machine assembly, showing the gearbox and generator components.

The interface also includes a left-hand navigation tree with various system components and a bottom toolbar with 'Update', 'Logbook', and 'Analysis' buttons.

In the general information, the machine details that were entered during the [configuration](#) are shown. Additionally the sensor positioning from the [configuration](#) is displayed. Furthermore the user comments that are not yet expired are shown. The user comments can also be deleted in this view.

8.2 Sensor Overview

The sensor overview states all relevant data of all configured sensors. Dependent of the connected channel the following information are shown:



IEPE

State of broken wire detection connected or not connected

Last characteristic value Dependent of the configured characteristic values the r.m.s. of the vibration velocity or vibration acceleration based on DIN-ISO 10816-21 or DIN-ISO 10816-3 is shown.


Process channels

The last momentary value is shown

Speed

The last measured speed value is shown

8.3 Alarms Vibration Diagnosis



The overview for the alarms of the vibration diagnosis contains detailed notifications for found irregularities on individual drive elements. The corresponding measurement data can directly be shown in the analysis from this notifications.

By clicking the green check individual alarms or all alarms of one drive element of all existing alarm can be acknowledged. It will be asked whether the acknowledgment should be done with or without increase of the alarm threshold. A default value is given for the alarm threshold increase. This default value can be changed in the menu Extras → Options in the tab Alerting.

If a rolling bearing or other drive element was exchanged, the corresponding alarm thresholds must be also reset. A button in the top row "reset drive element" provides this functionality. In the opening dialog it can be chosen between resetting one specific or all drive elements.

After the next synchronization with the Peakalyzer, the alarms will be acknowledged or reset on the Peakalyzer. Thus it is possible to handle all alarms without a direct connection or waiting for a connection to the Peakalyzer.

8.4 Alarms Characteristic Values

If the configuration contains alarm thresholds for characteristic values, notifications about threshold exceedments are listed in this box.

They can be individually acknowledged by clicking the red check and optionally modifying the threshold. A reset of the alarm threshold will set the threshold to the value when the configuration was transmitted to the Peakalyzer.

8.5 Alarms Process Factors

If the configuration contains alarm thresholds for process factors, notifications about threshold violations are listed in this box.

They can be individually acknowledged by clicking the red check and optionally modifying the threshold. A reset of the alarm threshold will set the threshold to the value when the configuration was transmitted to the Peakalyzer.

9 Analysis

9.1 Data Selection

Measurement data that should be visualized in a curve window can be selected in the data selection tree. For each data type a different curve window is used. There can be up to 10 signals of the same data type be visualized in a row or on top of each other. Multiple signals can be selected by holding the Ctrl-Key and clicking with the left mouse button. To select a block of measurement data, the Shift key can be hold while selecting a signal within data type with the left mouse button.

Spectra/Time Signals

The context menu allows to additional selecting data that was generated in the same measurement. So it is possible to show the related speed signal of an order spectrum if it was saved in this measurement. Furthermore the same data type of another sensor can be shown. It is automatically the measurement chosen that is closest to the current measurement.

Via the context menu the selected signal can also be exported to raw-Format (.raw), GfM-Intern Format (.grw) or ASCII-Format (.asc) to edit or view them with other programs. Additionally time signals can be exported to the .wav-Format and play them in an external Audio-Player. Alternatively the time signals can be outputted via the internal player to the standard output of the sound card.

Diagnostic Attributes

The diagnostic attributes that are also used for the alarm determination can be displayed for each configured drive element. The context menu offers the option to display the amplitude, order or DVS value of the diagnostic attributes. Also an combination of these types is possible. For these data types a trend can additionally visualized in an configurable time interval. Thus the evolution of the irregularities can be tracked over a longer period.

Process Factors

All permanent measured signals can be displayed in this section. That are all statistical types that were configured for the process channels. Additionally the minimum, maximum and arithmetic average of all configured and permanent measured speed channels can be displayed.

9.2 Curve Window

Following an overview of the control of the curve window is listed:

Key	Action
Cursor left/right	at activated cursor: Movement of the cursor to the left/right
Alt + Cursor left/right	move the X-axis to the left/right
Ctrl + Cursor left/right	at activated cursor: extended functionality of the cursor
Shift + Cursor left/right	at activated measurement cursor: move both cursor, that the distance between both cursor stays the same
mouse wheel up/down	zoom out/zoom in on both axis
Shift + mouse wheel up/down	zoom out/zoom in on the X-axis
Ctrl + mouse wheel up/down	zoom out/zoom in on the Y-axis
Ctrl + Alt + mouse wheel up/down	zoom out/zoom in on the active Y-axis if the data is visualized on top of each other
right mouse button + move mouse	Move the curve window in both axis directions


Shift + right mouse button	zoom out the X-axis
Shift + left mouse button	zoom in the X-axis
Ctrl + right mouse button	zoom out the Y-axis
Ctrl + left mouse button	zoom in the Y-axis
left mouse button + move mouse	zoom in the X-axis to the marked area

9.3 Toolbar

On the tool bar are the following functions available for manipulating the visualization of the curve window:

Rezoom


The axis of the chosen curve window are set that the whole data is visible.



Zoom on diagnostic attributes

The axis of the chosen curve window are set that the diagnosis attributes of the selected drive element are shown. In the menu Options on the tab Visualization → Diagnosis attributes the behavior of the zooming can be adjusted. The following options are available:

- *no zoom on diagnostic attributes* Zoom on diagnostic attributes has the same functionality as Rezoom
- *zoom left and right on diagnostic attribute* The X axis will be set that the selected diagnostic attribute is in the center of the curve window
- *zoom from 0 to diagnostic attribute* The X axis will be set that the curve window is shown from 0 to the selected diagnostic attribute



Last zoom position

The curve window will be reset to the last used axis positions.

Measurement Cursor

Places a measurement cursor for measuring distances, frequencies and orders in a chosen curve window. Also see Measurement Cursor.

Harmonic Cursor

Places an harmonic cursor on the chosen curve window. This cursor is only usable for spectra. Also see Harmonic Cursor.

Sideband Cursor



Places a sideband cursor on the chosen curve window. This cursor is only usable for spectra. Also see Sideband Cursor.

Marking Cursor

Places a marking cursor in the chosen curve window. Also see Marking Cursor.

Print Preview / Normal View

All curve window are visualized as in the options defined color scheme. The following default color schemes are available:



Clipboard

Copy the selected curve window to the clipboard. In the options on the tab Visualization → Clipboard, it can be chosen whether the print view should be used for copying. If this option is deactivated, the currently activated color scheme is used. The data is copied as vector graphic into the clipboard to have the optimal resolution on a printed document. It is advised to use a printer driver that is based on PCL5e since this driver can better handle large vector graphics.

Print


The chosen curve window is printed with the print view color schema via the default printer dialog. It is advised to use a printer driver that is based on PCL5e since this driver can better handle large vector graphics.

Activate 2D View

Changes the view to 2D-View. The data for the 3D-View will remain in the background to allow a fast switch between these two views.


In a row

In all curve windows the shown data will be visualized in a row with one Y-Axis.





On top of each other

In all curve windows the shown data will be visualized on top of each other with multiple Y-Axis.




Legend on/off

The legend can be faded in or out for the selected data. The following pictures show the visualization with and without legend.



Educed spectra

For frequency and order spectra the spectra of vibration acceleration, vibration velocity and vibration distortion are visualized on top of each other. If vibration acceleration data is saved, the vibration velocity and vibration distortion spectra are educed by integrating the vibration acceleration spectra. If vibration distortion data is saved, the vibration velocity and vibration acceleration spectra are educed by differentiating the vibration distortion spectra. For order spectra the average speed during the measurement time is used to calculate the other spectra.




Activate 3D View

Changes the view to the 3D-View. In this view, the spectrogram or waterfall for data of one sensor can be displayed. The sensor data with a check in the data tree view will be displayed.


Spectrogram

Shows the spectrogram of the data that are selected for the 3D-View.



Waterfall

Shows the waterfall of the data that are selected for the 3D-View.



Spectra of vibration acceleration

The spectra of vibration acceleration are used for the 3D-View. If the vibration distortion spectra are saved the vibration acceleration spectra are educed by differentiating the vibration distortion spectra two times. For order spectra the average speed during the measurement time is used to calculate the other spectra.

Spectra of vibration velocity


The spectra of vibration velocity are used for the 3D-View. If the vibration acceleration spectra are saved the vibration velocity spectra are educed by integrating the vibration acceleration spectra one time. If the vibration distortion spectra are saved the vibration velocity spectra are educed by differentiating the vibration distortion spectra one time. For order spectra the average speed during the measurement time is used to calculate the other spectra.

Spectra of vibration distortion

The spectra of vibration distortion are used for the 3D-View. If the vibration acceleration spectra are saved the vibration distortion spectra are educed by integrating the vibration acceleration spectra two times. For order spectra the average speed during the measurement time is used to calculate the other spectra.


Trend on/off

An additional trend for a configurable interval can be faded in for data like process factors, characteristic values or diagnostic attributes.



Thresholds on/off

If the currently selected data has configured alarm or warn thresholds, they can be faded in or out. This option is only available for process factors, characteristic values and diagnostic attributes.




Diagnosis Range on/off

If a selected data set (process factor or speed) is configured as diagnosis condition, the range can be faded in or out.

9.4 Cursor

9.4.1 Measurement Cursor

The measurement cursor has functionalities to measure relevant quantities of machine diagnostic and signal theory. It consist of two separate cursor that can be moved independently of each other. The distance of the cursors can be fixed to move both cursors when one is moved.



The following information are displayed in the cursor overview on the right side bar:


- X- and Y-Coordinate of the cursor positions
- distance of both cursor positions on the X-axis (dX)
- inverted distance of both cursor positions on the X-axis (1 / dX), e.g. to measure a frequency in a time signal
- approximate r.m.s. of vibration velocity (vEff) at the cursor positions. In order spectra of vibration acceleration the average speed during the measurement is used to calculate the vibration velocity.

The measurement cursor can be completely controlled with the mouse by positioning the cursor via Drag & Drop. It is also possible to control the measurement cursor with the keyboard. The following keys are available:

Key	Action
Cursor left	the first measurement cursor is moved one sample to the left
Cursor right	the first measurement cursor is moved one sample to the right
Ctrl + Cursor left	the second measurement cursor is moved one sample to the left
Ctrl + Cursor right	the second measurement cursor is moved one sample to the right
Shift + Cursor left	both measurement cursor are moved one sample to the left
Shift + Cursor right	both measurement cursor are moved one sample to the right

9.4.2 Harmonic Cursor

The harmonic cursor is a special measurement cursor to determine harmonic distances in spectra. The harmonic cursors are distributed over the whole spectrum. If the harmonic distance is made smaller or bigger, the number of harmonic cursors will be automatically adopted.



The following information are displayed in the cursor overview and can be manipulated on the right side bar:


- harmonic distance between two single harmonic cursor
- offset to search for harmonic families in the spectrum
- fixing the cursor number that controls the position of the whole harmonic cursor
- fixing the number of entitled cursor
- a text that is written on all entitled cursor

The harmonic cursor can be completely controlled with the mouse by positioning the cursor via Drag & Drop. It is also possible to control the harmonic cursor with the keyboard. The following keys are available:

Key	Action
Cursor left	the harmonic distance is reduced by one sample
Cursor right	the harmonic distance is increased by one sample
Ctrl + Cursor left	the second measurement cursor is moved on sample to the left
Ctrl + Cursor right	the second measurement cursor is moved on sample to the right

9.4.3 Sideband Cursor

The harmonic cursor is a special measurement cursor to determine harmonic distances in spectra. The harmonic cursors are distributed over the whole spectrum. If the harmonic distance is made smaller or bigger, the number of harmonic cursors will be automatically adopted.



The following information are displayed in the cursor overview and can be manipulated on the right side bar:


- position of the main cursor on the X-Axis
- distance of the sideband cursor to each other
- fixing the number of displayed sideband cursor
- a text that is written on the main cursor
- a text that is written on all entitled sideband cursor

The sideband cursor can be completely controlled with the mouse by positioning the cursor via Drag & Drop. It is also possible to control the sideband cursor with the keyboard. The following keys are available:

Key	Action
Cursor left	the position of the main cursor and all sideband cursor is moved one sample to the left
Cursor right	the position of the main cursor and all sideband cursor is moved one sample to the right
Ctrl + Cursor left	the distance of the sideband to each other is decreased by one sample
Ctrl + Cursor right	the distance of the sideband to each other is increased by one sample

9.4.4 Marking Cursor

The marked cursor is a simple cursor that allows to mark certain peaks or points in one data set.



The following information are displayed in the cursor overview and can be manipulated on the right side bar:


- position of the cursor on the X-Axis
- a text that is displayed at the marked cursor

The marked cursor can be completely controlled with the mouse by positioning the cursor via Drag & Drop. It is also possible to control the marked cursor with the keyboard. The following keys are available:

Key	Action
Cursor left	the position of the marked cursor is moved one sample to the left
Cursor right	the position of the marked cursor is moved one sample to the right

9.5 Filter Settings

By adjusting the filter settings the visible data in the data selection tree can be individually adopted.



The following filter options are available:

Date

Allows to reduce the displayed data to the set time frame. By default the last 3 months are displayed.

Diagnosis range

Allows to reduce the displayed data to a configured diagnosis range where an analysis has taken place. By default all diagnosis ranges are displayed.

Speed range


Allows to reduce the displayed data to a certain speed range.

Process range

Allows to reduce the displayed data to a certain process range. The information for the process channels are read from the configuration of the Peakalyzer.


9.6 Selection of Diagnostic Attributes

The diagnostic attributes can be faded in for each configured drive element. The drive element and corresponding damage pattern can be selected in the right side bar. This functionality is only available if a spectrum was selected in the data selection tree. In the following picture is a local tooth damage of a gear box displayed.



9.7 Trend Visualisation

A trend can be displayed additionally for measured data like process factors, characteristic values or diagnostic attributes. This is useful to observe the long-term evolution of the signal. The Trend can be activated and configured on the right side bar. The interval for the averaging can be set as a parameter. The visualization of the trend is only possible if one of the above stated data types is displayed. The following picture shows a trend with an interval of 5 days additionally to the measured process factor.



GfM Gesellschaft für Maschinendiagnose mbH

**Koepenicker Strasse 325
12555 Berlin
Deutschland – Germany**

**Phone Berlin
+49 / 30 / 65 76 25 65**

**Phone Dortmund
+49 / 231 / 77 64 723**

www.maschinendiagnose.de